

User Manual

96A0451

Retain for future use.

Rev. C, 3/8/13

ETL Certified to FAA Specification
150/5345-10

CSF (Ferroresonant) L-828 / L-829 Constant Current Regulator Air-Cooled, 2.5-30 kW, 6.6A / 20A



Disclaimer

This manual could contain technical inaccuracies or typographical errors. ADB Airfield Solutions reserves the right to revise this manual from time to time in the contents thereof without obligation of ADB Airfield Solutions to notify any person of such revision or change.

Details and values given in this manual have been compiled with care. They are not binding, however, and ADB Airfield Solutions disclaims any liability for damages or detriments suffered as a result of reliance on the information given herein or the use of products, processes or equipment to which this manual refers. No warranty is made that the use of the information or of the products, processes or equipment to which this manual refers will not infringe any third party's patents or rights.

Warranties

Products of ADB Airfield Solutions manufacturer guarantees the equipment has been manufactured and will perform in accordance with applicable specifications and that any defect in design, materials, (excluding lamps), or workmanship which may occur during proper and normal use during a period of 1 year from date of installation or at least 2 years from date of shipment will be corrected by repair or replacement by the manufacturers f.o.b. factory.

ADB Airfield Solutions will correct by repair or replacement, at its option, equipment or parts which fail because of mechanical, electrical or physical defects, provided that the goods have been properly handled and stored prior to installation, properly installed and properly operated after installation, and provided further that Buyer gives ADB Airfield Solutions written notice of such defects after delivery of the goods to Buyer. Refer to the Safety section for more information on Material Handling Precautions and Storage precautions that must be followed.

ADB Airfield Solutions reserves the right to examine goods upon which a claim is made. Said goods must be presented in the same condition as when the defect therein was discovered. ADB Airfield Solutions further reserves the right to require the return of such goods to establish any claim.

ADB Airfield Solutions' obligation under this guarantee is limited to making repair or replacement within a reasonable time after receipt of such written notice and does not include any other costs such as the cost of removal of defective part, installation of repaired product, labor or consequential damages of any kind, the exclusive remedy being to require such new parts to be furnished.

ADB Airfield Solutions' liability under no circumstances will exceed the contract price of goods claimed to be defective. Any returns under this guarantee are to be on a transportation charges prepaid basis. For products not manufactured by, but sold by ADB Airfield Solutions, warranty is limited to that extended by the original manufacturer.

This is ADB Airfield Solutions' sole guarantee and warranty with respect to the goods; there are no express warranties or warranties of fitness for any particular purpose or any implied warranties of fitness for any particular purpose or any implied warranties other than those made expressly herein. All such warranties being expressly disclaimed.

Trademarks

General notice: other product names used here are for identification purposes only and may be trademarks of their respective companies.

Proprietary Information

This information carrier contains proprietary information, which shall not be used for other purposes than those for which it has been released, nor be reproduced or disclosed to third parties without the prior written consent of ADB Airfield Solutions.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, mechanical, photocopy, recording, or otherwise, without the prior written permission of ADB Airfield Solutions. No patent liability is assumed with respect to the use of the information contained herein. Neither is any liability assumed for damages resulting from the use of the information contained herein.

ADB Airfield Solutions shall not be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by purchaser or third parties as a result of accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product. ADB Airfield Solutions shall not be liable against any damages arising from the use of any options or parts other than those designated as approved products.

Copyright © 2010 by ADB Airfield Solutions. All rights reserved.

TABLE OF CONTENTS

CSF (Ferroresonant) L-828 / L-829 Constant Current Regulator	i
1.0: Safety	1
1.1 :To use this equipment safely	1
1.1.1 :Additional Reference Materials	1
1.1.2 :Qualified Personnel	1
1.1.3 :Intended Use	1
1.1.4 :Storage	1
1.1.4.1 :Operation	2
1.1.4.2 :Material Handling Precautions	2
1.1.4.3 :Action in the Event of a System or Component Malfunction.....	2
1.1.4.4 :Maintenance and Repair.....	2
1.1.4.5 :Operation of Overloaded Regulators	2
2.0: Introduction	3
2.1 :About this manual	3
2.1.1 :How to work with the manual	3
2.1.2 :Record of changes	3
2.2 :Product Introduction	4
2.3 :Compliance with Standards	4
2.4 :Features	4
2.5 :Electrical Supply	5
2.5.1 :Remote Control	5
2.5.2 :Total Harmonic Distortion* (THD)	5
2.5.3 :Theory of Operation Introduction	5
2.6 :ACE2 Unit	5
2.7 :Environmental Operating Conditions	6
2.7.1 :Monitoring Option	6
2.7.2 :Application Notes	7
2.8 :Theory of Operation	8
2.8.1 :Power Circuit	8
2.8.2 :Output Measurement	8
2.8.3 :Control PCB	8
2.8.3.1 :Control PCB Inputs/Outputs	8
2.8.4 :Output Current Monitor Circuitry	9
2.8.5 :Local Control Position Detection	9
2.8.6 :Contactor Drive	9
2.8.7 :Remote Control Position Detection	9
2.8.8 :Fault Protection	9
2.9 :L-828 CCR	10
2.10 :L-829 CCR	11
2.11 :CCR Controller	12
2.11.1 :L-829 Advanced Control Equipment (ACE or ACE2)	12
2.12 :L-828/L-829 CCR Monitoring Options	13
2.12.1 :Optional Insulation Resistance Monitoring System	13
2.13 :Optional Series Cutout Type SCO	13
2.14 :Optional Current Clamp Test Point	13
2.15 :L-828 CCRs Required Equipment	13
2.16 :Input Wire Size	14
2.17 :Input Power Breaker Sizing	14
2.18 :Specifications	15
2.18.1 :Efficiency	15
2.18.2 :Reactive Loading	15
2.18.3 :Resistive Loading	15
2.18.4 :Regulation	15
2.18.5 :Environmental Operating Conditions	16

2.18.6 :Protection Devices	16
2.18.6.1 :Open-Circuit Protection.....	16
2.18.6.2 :Overcurrent Protection	16
2.18.7 :Input Voltage	16
2.18.7.1 :Built-In True-rms-Reading Ammeter, L-828 only	16
2.18.8 :Temperature Rise	16
2.19 :Weights	17
2.20 :Dimensions	18
3.0: Installation	19
3.1 :Unpacking	19
3.2 :Installation	19
3.2.1 :Wiring Connections and Startup	19
3.3 :Frames	22
4.0: Operation	23
4.1 :Introduction	23
4.2 :CCR Control Procedures	23
4.2.1 :Local Control	23
4.2.2 :Remote Control	24
4.3 :CCR Door Interlock	24
4.4 :CCR Shutdown Procedure	24
4.5 :CCR Adjustment Procedures	24
4.5.1 :Output Current Adjustment	25
4.5.2 :Adjusting Output Current	26
4.5.2.1 :Adjusting Overcurrent Control Board	27
4.6 :SCO Cutout Working Positions	28
4.7 :Application Notes	30
4.8 :Digital Power Meter Calibration (optional)	31
4.8.1 :Display	31
4.8.2 :Function Buttons	31
4.8.3 :DPM Displays	31
4.8.4 :Calibration Procedure	32
5.0: Maintenance and Repair	35
5.1 :Maintenance Schedule	35
5.1.1 :Short-Circuit Test	36
5.1.2 :Open-Circuit Test	36
5.2 :Troubleshooting	37
5.2.1 :Preliminary Troubleshooting	37
5.2.2 :Troubleshooting Control Board	38
5.2.3 :Troubleshooting Fuses	39
5.2.4 :L-828 General Troubleshooting	49
5.3 :Additional L-829 General Troubleshooting Procedures	50
5.4 :Component Replacement Procedures	51
5.4.1 :Removing and Replacing Control PCB	51
5.4.2 :Removing and Replacing Dual SCR Module Assembly	52
5.4.3 :Removing and Replacing Contactor	53
5.4.4 :Removing and Replacing Input Lightning Arrestors (front of Component Mounting Plate)	54
5.4.5 :Removing and Replacing Output Lightning Arrestors	54
6.0: Parts and Mechanical Drawings	55
7.0: Wiring Schematics	59

1.0 Safety

This section contains general safety instructions for installing and using ADB Airfield Solutions equipment. Some safety instructions may not apply to the equipment in this manual. Task- and equipment-specific warnings are included in other sections of this manual where appropriate.

1.1 To use this equipment safely



WARNING

Read installation instructions in their entirety before starting installation.

- Refer to the FAA Advisory Circular AC 150/5340-26, Maintenance of Airport Visual Aids Facilities, for instructions on safety precautions.
- Observe all safety regulations. To avoid injuries, always disconnect power before making any wiring connections or touching any parts. Refer to FAA Advisory Circular AC 150/5340-26.
- Become familiar with the general safety instructions in this section of the manual before installing, operating, maintaining or repairing this equipment.
- Read and carefully follow the instructions throughout this manual for performing specific tasks and working with specific equipment.
- Make this manual available to personnel installing, operating, maintaining or repairing this equipment.
- Follow all applicable safety procedures required by your company, industry standards and government or other regulatory agencies.
- Install all electrical connections to local code.
- Use only electrical wire of sufficient gauge and insulation to handle the rated current demand. All wiring must meet local codes.
- Route electrical wiring along a protected path. Make sure they will not be damaged by moving equipment.
- Protect components from damage, wear, and harsh environment conditions.
- Allow ample room for maintenance, panel accessibility, and cover removal.
- Protect components from damage, wear, and harsh environment conditions.
- Allow ample room for maintenance, panel accessibility, and cover removal.
- Protect equipment with safety devices as specified by applicable safety regulations.
- If safety devices must be removed for installation, install them immediately after the work is completed and check them for proper functioning prior to returning power to the circuit.

1.1.1 Additional Reference Materials

- NFPA 70B, Electrical Equipment Maintenance.
- NFPA 70E, Electrical Safety Requirements for Employee Workplaces.
- ANSI/NFPA 79, Electrical Standards for Metalworking Machine Tools.
- OSHA 29 CFR, Part 1910, Occupational Health and Safety Standards.
- National and local electrical codes and standards.

1.1.2 Qualified Personnel

The term **qualified personnel** is defined here as individuals who thoroughly understand the equipment and its safe operation, maintenance and repair. Qualified personnel are physically capable of performing the required tasks, familiar with all relevant safety rules and regulations and have been trained to safely install, operate, maintain and repair the equipment. It is the responsibility of the company operating this equipment to ensure that its personnel meet these requirements.

Always use required personal protective equipment (PPE) and follow safe electrical work practices.

1.1.3 Intended Use



WARNING

Using this equipment in ways other than described in this manual may result in personal injury, death or property and equipment damage. Use this equipment only as described in this manual.

ADB Airfield Solutions cannot be responsible for injuries or damages resulting from nonstandard, unintended applications of its equipment. This equipment is designed and intended only for the purpose described in this manual. Uses not described in this manual are considered unintended uses and may result in serious personal injury, death or property and equipment damage. Unintended uses may result from taking the following actions:

- Making changes to equipment that are not recommended or described in this manual or using parts that are not genuine ADB Airfield Solutions replacement parts.
- Failing to make sure that auxiliary equipment complies with approval-agency requirements, local codes and all applicable safety standards.
- Using materials or auxiliary equipment that are inappropriate or incompatible with ADB Airfield Solutions equipment.
- Allowing unqualified personnel to perform any task.

1.1.4 Storage



CAUTION

If equipment is to be stored prior to installation, it must be protected from the weather and kept free of condensation and dust.

Failure to follow this instruction can result in injury or equipment damage.

1.1.4.1 Operation



WARNING

- Only qualified personnel, physically capable of operating the equipment and with no impairments in their judgment or reaction times, should operate this equipment.
- Read all system component manuals before operating this equipment. A thorough understanding of system components and their operation will help you operate the system safely and efficiently.
- Before starting this equipment, check all safety interlocks, fire-detection systems, and protective devices such as panels and covers. Make sure all devices are fully functional. Do not operate the system if these devices are not working properly. Do not deactivate or bypass automatic safety interlocks or locked-out electrical disconnects or pneumatic valves.
- Protect equipment with safety devices as specified by applicable safety regulations.
- If safety devices must be removed for installation, install them immediately after the work is completed and check them for proper functioning.
- Route electrical wiring along a protected path. Make sure they will not be damaged by moving equipment.
- Never operate equipment with a known malfunction.
- Do not attempt to operate or service electrical equipment if standing water is present.
- Use this equipment only in the environments for which it is rated. Do not operate this equipment in humid, flammable, or explosive environments unless it has been rated for safe operation in these environments.
- Never touch exposed electrical connections on equipment while the power is ON.

1.1.4.2 Material Handling Precautions



CAUTION

This equipment may contain electrostatic sensitive devices.

- Protect from electrostatic discharge.
- Electronic modules and components should be touched only when this is unavoidable e.g. soldering, replacement.
- Before touching any component of the cabinet you should bring your body to the same potential as the cabinet by touching a conductive earthed part of the cabinet.
- Electronic modules or components must not be brought in contact with highly insulating materials such as plastic sheets, synthetic fiber clothing. They must be laid down on conductive surfaces.
- The tip of the soldering iron must be grounded.
- Electronic modules and components must be stored and transported in conductive packing.

1.1.4.3 Action in the Event of a System or Component Malfunction



WARNING

- Do not operate a system that contains malfunctioning components. If a component malfunctions, turn the system OFF immediately.
- Disconnect and lock out electrical power.
- Allow only qualified personnel to make repairs. Repair or replace the malfunctioning component according to instructions provided in its manual.

1.1.4.4 Maintenance and Repair



WARNING

Allow only qualified personnel to perform maintenance, troubleshooting, and repair tasks.

- Only persons who are properly trained and familiar with ADB Airfield Solutions equipment are permitted to service this equipment.
- Disconnect and lock out electrical power.
- Always use safety devices when working on this equipment.
- Follow the recommended maintenance procedures in the product manuals.
- Do not service or adjust any equipment unless another person trained in first aid and CPR is present.
- Connect all disconnected equipment ground cables and wires after servicing equipment. Ground all conductive equipment.
- Use only approved ADB Airfield Solutions replacement parts. Using unapproved parts or making unapproved modifications to equipment may void agency approvals and create safety hazards.
- Check interlock systems periodically to ensure their effectiveness.
- Do not attempt to service electrical equipment if standing water is present. Use caution when servicing electrical equipment in a high-humidity environment.
- Use tools with insulated handles when working with electrical equipment.

1.1.4.5 Operation of Overloaded Regulators



WARNING

- Operation of a Regulator while overloaded at any step may result in equipment failure or equipment damage.

2.0 Introduction

2.1 About this manual

CSF (Ferroresonant) L-828 / L-829 Constant Current Regulator

The manual shows the information necessary to:

- Install
- Carry Out Maintenance
- Carry Out Troubleshooting

on the CSF (Ferroresonant) L-828 / L-829 Constant Current Regulator, in the manual referred to as the equipment.

2.1.1 How to work with the manual

1. Familiarize yourself with the structure and content.
2. Carry out the actions completely and in the given sequence.

2.1.2 Record of changes

[illegible]

2.2 Product Introduction



WARNING

Read the instructions in their entirety before starting installation.

This section describes the ADB Airfield Solutions Ferroresonant, L-828/L-829, constant current regulators (CCRs). These CCRs are manufactured according FAA specification AC 150/5345-10 (latest edition).

2.3 Compliance with Standards

FAA:

L-828/L-829 AC 150/5345-10 (Current Edition) ETL Certified

ICAO:

Aerodrome Design Manual Part 5, para. 3.2.1.4 to 3.2.1.6

Military:

UFC 3-535-01; NAVAIR 51-50AAA-2

Uses:

Supplies three or five precision output levels to power series lighting circuits on airport runways and taxiways.

2.4 Features

- Advanced CCR architecture combines the performance advantages of both saturable reactor and Ferroresonant technologies. Produces minimal EMI, high efficiency, and near unity power factor for AC 150/5345-10 test conditions, exceeding FAA and military requirements for power factor and efficiency. Unique CCR design has excellent input power factor and efficiency at all intensity steps and lower loads.
- Does not exceed the conducted power line emission limits given in Table 4 of AC 150/5345-10 (latest edition) with testing as specified by the Federal Communications Commission (FCC) in the Code of Federal Regulations (CFR) Title 47, Subpart B, Section 15.107b. Does not exceed the radiated emission limits given in Table 5 of AC 150/5345-10 with testing as specified in the Code of Federal Regulations (CFR) Title 47, Subpart B, Section 15.109b.
- Optional integrated ACE™ unit provides state-of-the-art remote control and L-829 monitoring capability. Unique “cycle” mode allows display of True-RMS current and voltage, VA, watts, lamps-out, and series circuit insulation resistance value to be alternately displayed. A visual indication is also provided for all other FAA-monitored parameters, including open circuit, overcurrent, loss of input power, loss of input voltage, low VA (drop in load VA of 10%), Remote/Local status, and incorrect output current.
- No input turn on in-rush current surge.
- To minimize the floor space required in a vault, ADB 2.5-30kW regulators can be stacked using a stacking kit. See Kits section for details.
- Available in two classes and styles:
 - Class 1 = 6.6A maximum output current
 - Class 2 = 20A maximum output current (15-30kW only)
 - Style 1 = 3 Brightness Steps
 - Style 2 = 5 Brightness Steps
- If input power loss occurs, operation will resume within five seconds after restoration of input power.
- Brightness Steps can be changed in the field (between 3 and 5 Steps). New label required.
- Field upgradable from L-828 to L-829 with ACE unit.
- Industrial powder coat finish.
- Input lightning protection and output lightning protection included.

2.5 Electrical Supply

Table 1: Power Input

frequency	power (Vac)
50 hz	220, 230, 240, 380, 400
60Hz	208, 220, 240, 347, 380, 480, 600

Power Factor*: 0.99 or more for 2.5 to 30kW at highest step.

NOTE: Efficiency at highest step

90% minimum for 2.5 to 25kW

92% minimum for 30kW

2.5.1 Remote Control

120V AC, or +48V DC, $\pm 10\%$

2.5.2 Total Harmonic Distortion* (THD)

Current THD: 10% maximum in highest step

Voltage THD: 1.9% maximum in all steps

* Tested with 100% resistive load according to FAA AC150/5345-10 (Latest Edition).

2.5.3 Theory of Operation Introduction

Ferroresonant circuitry and a solid-state control system accurately regulate the output current to within the FAA-allowable range from no load to full load and with input voltage variations of -5% to +10% of nominal.

For more theory of operation see: "Theory of Operation" on page 8.

2.6 ACE2 Unit

The ACE2TM unit provides L-829 monitoring and optional megging or CCR input monitoring capability. Each unit is installed locally at each CCR that requires remote control and/or monitoring within the airfield lighting electrical vault. Optional CCR input monitoring monitors the following:

- CCR input current
- CCR input voltage
- CCR input volt-amps (VA)
- CCR input power (watts)
- CCR input power factor
- CCR % efficiency

The ACE2 unit is also a component of ADB's distributed control and monitoring system. Each unit can be easily connected to an Airport Lighting Control & Monitoring System (ALCMS) by simply adding redundant communication wires. See ADB ACE2 catalog sheet 2084 for additional information.


2.7 Environmental
Operating Conditions

- Temperature: -40°C to +55°C (-40°F to +131°F)
- Humidity: 10 to 95%
- Altitude: 0 to 6,600 ft (2,000 m)

2.7.1 Monitoring Option

See Figure 1

Figure 1: CSF Ordeing Codes



Notes

- A ferroresonant CCR is preferred for airports that require low output harmonic content (EMI) or that have varying loads, such as Runway Guard Lights using incandescent (tungsten-halogen) lamps, L-849 REILs using xenon flash lamps, or Runway Status Lights (RWSL)
- Runway Guard Lights using incandescent (tungsten-halogen) lamps should be powered with ferroresonant type CCRs and not with thyristor type CCRs
- Refer to catalog sheet 3013 for 20 A 50 and 70 kW CCRs.
- ¹ 3-step, 20 A is not standard FAA operation. ADB Airfield Solutions can offer a non-ETL Certified Style 1, Class 2 CCR for dedicated 5.5 A sign circuits or other needs. Please contact the ADB Sales Department for more details.
- ² Used only with Monitoring Options 0 and 6.
- ³ Used only with Monitoring Options 3 and 5.

2.7.2 Application Notes

0 None Standard

L-828 supplied with analog ammeter

3 L-829 Monitoring (ACE™)

Includes FAA L-829 monitoring equipment.

If application is for connection to ADB L-890 **ALCMS**: Add a “/A” to end of Ordering Code. The ACE unit will then be programmed to provide monitoring data via dual redundant communication links. If application is for a stand-alone L-829 CCR: Ordering Code is not changed. The ACE unit is programmed to deactivate a dry contact closure if a fault is present. The fault alarm can then be connected to any external monitoring system.

4 Insulation Resistance Monitoring System (IRMS) Ready

This option adds an IRMS board in the CCR. Application: connection to externally mounted ADB ACE unit.

5 L-829 Monitoring (ACE) Includes FAA L-829 and IRMS equipment and IRMS

- If application is for connection to ADB L-890 **ALCMS**: Add a “/A” to end of Ordering Code. The ACE unit will then be programmed to provide monitoring data via dual redundant communication links.
- If application is for a stand-alone L-829 CCR with Insulation Resistance Monitoring: Ordering Code is not changed. The ACE unit is programmed to activate a dry contact closure if a fault is present. The fault alarm can then be connected to any external monitoring system.

6 L-828 with Digital Power Meter

This option replaces the analog ammeter with a Digital Power Meter. The Digital Power Meter is used on L-828 CCRs to indicate True RMS output current, voltage, VA, and watts. It can also be set to activate an alarm if there is a 10% or 15% drop in the load (Low VA).

2.8 Theory of Operation

2.8.1 Power Circuit

This subsection describes the L-828 CCR theory of operation.

See Figure 2. A Ferroresonant network consisting of T1, C1, and the SCRs draw from the input lines. This network is capable of drawing a limited amount of power. It can be routed to one of two places. The first is the output leads to the airfield. The second is a resonant tank comprised of C1 and part of T1.

As more power is allowed to flow into the resonant tank, less is available to flow to the field. It is by regulating the current in this tank that the SCRs regulate throughput current to the airfield. It is important to note that the output of the regulator will be the smallest when the SCRs are conducting 100% of the time. This is the opposite of what is seen in simple SCR regulators where the SCRs are used to directly control the output of the regulator.

NOTE: C1 is actually a bank of capacitors located near T1.

The components of the Ferroresonant network are designed to deliver an output current slightly higher than 6.6 A/20 A for the minimum input voltage, while the SCRs are fully off.

2.8.2 Output Measurement


The output current flows through the high voltage current transformer T5. T5 provides feedback to the Control PCB on the actual current output to the airfield series circuit.

A second current transformer, T2, provides current to a true-rms-reading ammeter mounted onto the front panel to indicate output current.

2.8.3 Control PCB

See Figure 5. This subsection describes the board level circuitry found on the Control PCB.

Figure 2: L-828 CCR Power Circuit Block Diagram



2.8.3.1 Control PCB Inputs/Outputs

The Control PCB receives the inputs listed below. See Figure 5 in this section and "Wiring Schematics" on page 59.

- Local control signals from the front panel rotary switch.
- Remote control signals from a remote control terminal block located in the L-828 chassis (120Vac/48Vdc) (TB1).
- A current proportional to the output current from a current transformer (T5).
- Phase angle reference voltage derived from the input voltage.
- 24 Vac center tapped supply voltage from T4.
- The Control PCB provides the outputs listed below.
- A contact to complete the input contactor K1 coil circuit.
- A contact to enable the Remote CCI voltage at TB1.
- Gate drive signals to the SCR block used to regulate the output current.

2.8.4 Output Current Monitor Circuitry

The system output current is sensed by a current transformer (T5) whose secondary is connected to J8-3 and J8-4 on the Control PCB. This current signal is passed through a 15-ohm shunt resistor (R38), located on the Control PCB. For the 6.6 amp regulator, T5 provides a 100:1 step-down of the feedback current. For 20 A regulators, this ratio is 300:1. Output current steps 1-5 would correspond to voltage levels of 420, 510, 615, 780, and 990 millivolts respectively.

2.8.5 Local Control Position Detection

Local control position detection is accomplished by using a rotary switch mounted on the front door of the CCR. See Figure 3.

2.8.6 Contactor Drive

The contactor drive circuit on the Control PCB pulls in the main contactor K2 by shorting points J4-2 to J4-4.

2.8.7 Remote Control Position Detection

When the local control signal to the micro-controller indicates "remote" the remote control circuitry is active. Relay K1 on the Control PCB closes, providing 120VAC to the CCI connection on TB2. The remote control inputs incorporate surge suppression and are optically isolated from the rest of the PCB.

2.8.8 Fault Protection

This subsection describes CCR fault protection.

Overcurrent Protection

The micro-controller detects an over current condition by comparing the output current to a preset value. If the output current exceeds this value the controller will shut the regulator down by removing drive to the input contactor. This contactor will remain de-energized until the controller is reset either by selecting the OFF position (remotely or locally) or cycling the input power off for a minimum of 2 seconds and then back on. The control board will not recognize momentary over currents caused by load switching or other transient conditions.


Open Circuit Protection

The micro-controller detects an open circuit by the absence of current in the regulator output (this will also detect an open or shorted current transformer). If the output current is less than 1.5 amps, the controller will shut the current regulator down within one second by removing drive to the input contactor. This contactor will remain de-energized until the controller is reset either by selecting the OFF position (remotely or locally) or cycling the input power off for a minimum of 2 seconds and then back on.

2.9 L-828 CCR

See Figure 3. This subsection describes the L-828 CCR. The L-828 uses a Control PCB to provide regulator and control functions.

Figure 3: L-828 CCR (2.5 -30kW/6.6 A)



1 Ammeter (shown) or Digital Power Meter
2 Rotary Switch


The L-828 CCRs are designed to:

- Supply three or five precision output current levels (6.6 A/20 A maximum) to power airport series lighting circuits on runways and taxiways.
- Accurately regulate the output current to within $\pm 1\%$ of the adjustable nominal levels from no load to full load and with input voltage variations of -5% to $+10\%$ of nominal.
- Maintain the nominal output current levels even when 30 percent of the isolation transformers in the series lighting circuit supplied by the regulator have open secondaries.

2.10 L-829 CCR

See Figure 4. This subsection describes the L-829 CCR. The L-829 uses a Control PCB to provide regulator and control functions. It also uses the Advanced Control Equipment (ACE™ or ACE2™) for control and monitoring functions.

Figure 4: L-829 CCR with ACE2




- 1 ACE2 Front Panel Display
- 2 L-829 CCR
- 3 Rotary Switch

2.11 CCR Controller

See Figure 5 below. The CCR Controller is a PC board that is designed to provide all regulator and control functions for Ferroresonant L-828/L-829 CSF style manufactured by ADB Airfield Solutions. This is accomplished with a microcontroller and interface circuitry contained on a single 8 x 8 inch (203 mm x 203 mm) through-hole type printed circuit board. The regulator controller PCB performs the functions listed below.

- Produces SCR drive signals in accordance with the desired output current setting.
- Detects an overcurrent, or open circuit, and switches the constant current regulator off.
- When in Remote mode, enables the CCI to provide 120 Vac at 50 W. The CCI is the Remote power control source.

Figure 5: CCR Controller



2.11.1 L-829 Advanced Control Equipment (ACE or ACE2)

See Figure 4 and Figure 6. The L-829 ACE™ (or ACE2™) control and monitoring unit consists of an integrated control unit that is interfaced to each CCR either internally or within a small external enclosure. The ACE printed circuit boards are mounted inside a small and rugged environmental enclosure that is directly attached to the door of the L-829 CCR. The ACE consists of microprocessor-based module(s) that processes communication, control commands, input/output interface, and failsafe functionality for controlled elements in the airfield lighting vault.

Figure 6: ACE2 Control Board



For more information about the ACE, see:

- Advanced Control Equipment (ACE) manual 96A0287 or the Advanced Control Equipment (ACE2) manual 96A0357.
- ACE Programming manual 96A0348.

2.12 L-828/L-829 CCR Monitoring Options

2.12.1 Optional Insulation Resistance Monitoring System

The L-829 CCR monitoring options include the Insulation Resistance Monitoring System (IRMS), and ALCMS PLC Interface.

The IRMS is used only on the L-829. It performs scheduled cable insulation resistance measurements and can also perform manually requested measurements. IRMS provides the ability for monitoring the long-term degradation of the airfield series circuit cabling and showing the results on the L-829 CCR front display panel.



WARNING

When servicing a regulator equipped with an IRMS module, be sure that power to the IRMS is disconnected before touching the IRMS board, or any of the high voltage components or wires.

2.13 Optional Series Cutout Type SCO

The series cutout Type SCO is often used at airports having a large number of series circuits to isolate the series circuit from the CCR during maintenance or testing operations. It also allows manual measurement of resistance of the series circuit to ground without disconnecting the series cable. The SCO cutout has a nominal working voltage of 5 kV and a nominal carrying current capacity of 20 amps AC.

For more information refer to the SCO Cutout manual 96A0294.

2.14 Optional Current Clamp Test Point

Regulators without an optional Series Cutout Type SCO will have a current clamp test point installed to provide a location to attach an output current clamp when used to calibrate the output of the CCR.

2.15 L-828 CCRs Required Equipment

Refer to Table 2 for required equipment that is supplied.

Refer to Table 3 for required equipment that is not supplied.

Refer to "Parts and Mechanical Drawings" on page 55 for ordering information.

Table 2: Required Equipment Supplied

Description	Quantity
L-828/L-829 constant current regulator	As Req'd on Order
Instruction manual	1 per CCR on Order

Table 3: Required Equipment Not Supplied

Description	Quantity
Input power wire. Refer to Table 4.	As required
Remote control wire, AWG 18 minimum, AWG 14 maximum	As required
Ground wire, AWG 8 minimum (6.6 A); AWG 6 minimum (20 A)	As required
Output load wire, AWG 6 minimum, 5000 Vac, L-824 type (6.6 A); AWG 8 minimum (20 A)	As required
Shorting jumper wire, AWG 8 minimum	As required
Disconnect switch or main circuit breaker	1
Voltmeter, 60 Vdc full scale	1
Ammeter, true-rms-reading, 9 A maximum scale	1
Inductive-type current probe	1
Ohmmeter	1
Mounting bolts, 1/2-13 x 1-1/2 in. long, 1/2 STD washers, and lockwashers	4

2.16 Input Wire Size

Table 4 refers to recommended input power supply wire size for each regulator power rating dependent on the input voltage. This recommendation is based on 75°C rated copper wire per NEC Table 310.16.

Table 4: Recommended Input Wiring Rating

SIZE	208 V	220 V	230 V	240 V	347 V	380 V	400 V	480 V	600 V
2.5 kW	AWG 10	AWG 10	AWG 10*	AWG 10*	AWG 12	AWG 12*	AWG 12*	AWG 12	AWG 12
4 kW	AWG 10	AWG 10	AWG 10*	AWG 10*	AWG 12	AWG 12*	AWG 12*	AWG 12	AWG 12
5 kW	AWG 10	AWG 10	AWG 10	AWG 10	AWG 12*	AWG 12*	AWG 12*	AWG 12	AWG 12
7.5 kW	AWG 6	AWG 8	AWG 8	AWG 8	AWG 8	AWG 8	AWG 8	AWG 10*	AWG 10*
10 kW	AWG 4	AWG 6	AWG 6	AWG 6	AWG 8	AWG 8	AWG 8	AWG 10	AWG 10
15 kW	AWG 3	AWG 3	AWG 3	AWG 4	AWG 6	AWG 6	AWG 6	AWG 8	AWG 8
20 kW	AWG 2/0	AWG 1/0	AWG 1/0	AWG 2	AWG 4	AWG 4	AWG 4	AWG 6	AWG 6
25 kW	AWG 2/0	AWG 1/0	AWG 1/0	AWG 2	AWG 4	AWG 4	AWG 4	AWG 6	AWG 6
30 kW	AWG 3/0	AWG 3/0	AWG 2/0	AWG 2/0	AWG 2	AWG 2	AWG 2	AWG 4	AWG 4

*Increased 1 wire size to comply with small conductor limits in NEC 240.4(E) through (G)

2.17 Input Power Breaker Sizing

It is recommended that the circuit breaker on the input power supply lines have a rating of 125% of the CCR's input current, as given in Table 5, unless local codes require a different rating technique. Refer to the CCR's nameplate for the kW rating and input voltage to determine the actual input current from Table 5. If no standard-size circuit breaker exists at the 125% value, use the next larger standard-size circuit breaker.

NOTE: The currents listed in Table 5 represent actual input currents assuming the worst case limits of AC 150/5345-10 for power factor, efficiency, and number of required lamps out.

Table 5: CCR Input Voltage and Current for the CCR Power Ratings

SIZE	208 V	220 V	230 V	240 V	347 V	380 V	400 V	480 V	600 V
2.5 kW	17 A	16 A	15 A	15 A	10 A	10 A	9 A	8 A	6 A
4 kW	27 A	26 A	24 A	23 A	16 A	15 A	14 A	12 A	10 A
5 kW	34 A	32 A	30 A	29 A	20 A	19 A	18 A	15 A	12 A
7.5 kW	50 A	47 A	45 A	43 A	30 A	28 A	26 A	22 A	18 A
10 kW	67 A	63 A	60 A	58 A	40 A	37 A	35 A	29 A	23 A
15 kW	100 A	94 A	90 A	86 A	60 A	55 A	52 A	43 A	35 A
20 kW	133 A	125 A	120 A	115 A	80 A	73 A	69 A	58 A	46 A
25 kW	166 A	157 A	150 A	144 A	100 A	91 A	86 A	72 A	58 A
30 kW	195 A	185 A	177 A	169 A	117 A	107 A	102 A	85 A	68 A

2.18 Specifications

This subsection provides specifications for L-828/L-829 CCR (6.6 A/20 A).

Table 6: Class, Style and Power Ratings

Class	L-828/L-829 CCR Max Output Current	Style	Brightness Steps	Nominal Output Current	Power Ratings
1	6.6 A	1	3	4.8 A, 5.5 A, 6.6 A	2.5 - 30 kW
		2	5	2.8 A, 3.4 A, 4.1 A, 5.2 A, 6.6 A	
2	20 A	2	5	8.5 A, 10.3 A, 12.4 A, 15.8 A, 20 A	15 - 30 kW

Table 7: Power Factor

CCR	Power Factor
2.5 - 10 kW	0.90 minimum
15 -30 kW	0.95 minimum

2.18.1 Efficiency

The efficiency of the regulator operated with rated input voltage into a full load having unity power factor is not less than the value shown in Table 8.

Table 8: Efficiency

CCR	Efficiency
2.5-25 kW	90% minimum
30 kW	92% minimum

2.18.2 Reactive Loading

The CCR maintains the output current within the limits of Table 9 for all brightness steps when the load is connected via isolating transformers, and the secondaries of 30 percent of the transformers become open-circuited. The load before opening the isolation transformer secondaries may be any value from half to full load. For regulators less than 10 kW loaded as specified above, the current remains below 6.8 amperes for the 100 percent brightness step.

Table 9: Output Current and Limits

Class	Style	Step	Nominal output amperes (A) root mean square (RMS)	Allowable range (A RMS)
1	1	B100	6.6	6.5 - 6.7
		B30	5.5	5.4 - 5.6
		B10	4.8	4.7 - 4.9
1	2	B5	6.6	6.5 - 6.7
		B4	5.2	5.1 - 5.3
		B3	4.1	4.0 - 4.2
		B2	3.4	3.3 - 3.5
		B1	2.8	2.7 - 2.9
2	2	B5	20.0	19.7 - 20.3
		B4	12.8	15.5 - 16.1
		B3	12.4	12.1 - 12.7
		B2	10.3	10.0 - 10.6
		B1	8.5	8.2 - 8.8

2.18.3 Resistive Loading

The regulator maintains the output current within the limits of Table 9 while powering any load between no load (or short circuit) and full load. For regulators 10 kW or larger, the regulation is maintained over the full range of environmental conditions specified in this section and for the input voltages specified in Table 5. For regulators less than 10 kW, the regulation is provided at nominal input voltage for all brightness steps.

2.18.4 Regulation

Refer to Table 9 for output current limits. Current regulation is obtained under the conditions listed in *Environmental Operating Conditions*.

2.18.5 Environmental Operating Conditions

The L-828 CCRs are designed for indoor use only in an area with adequate ventilation for cooling the constant current regulator. The environmental operating conditions include temperature range, relative humidity, and altitude.

Table 10: Environmental Operating Conditions

Temperature Range		Relative Humidity	Altitude
Without monitoring circuitry	With monitoring circuitry		
-40 to +55 °C (-40 to +131 °F)	0 to +55 °C (-18 to +131 °F)	10 to 95% (non-condensing)	Sea level to 6,600 ft (2000 m)

2.18.6 Protection Devices

L-828 CCRs have the following protection devices:

- Output open-circuit protection.
- Output overcurrent protection.
- Lightning arrestors on output terminals and bushings.
- Lightning arrestors on input terminals.
- Fuse protection of AC supply voltage of the Control PCB and brightness control voltage for Remote control.

2.18.6.1 Open-Circuit Protection

The regulator includes an open-circuit protective device to open the primary switch within 2 seconds after an open circuit occurs in the secondary. The device resets within 2 seconds after the control switch is turned off and re-energized, and cannot be tripped by switching the load circuits or other transients.

2.18.6.2 Overcurrent Protection

Regulators include an overcurrent protective device that opens the primary switch when the output current exceeds the 100 percent current (6.6 A or 20 A) by 5 percent. The device operates within 5 seconds after an overcurrent of 5 percent and within 1 second after an overcurrent of 25 percent. The device resets within 2 seconds after the control switch is turned off and re-energized. The overcurrent protection cannot be activated by a momentary (0.25 second) overcurrent caused by switching the load circuits and other transients.

2.18.7 Input Voltage

Input voltage is single phase 50/60 Hz ac. Regulators operate as required (see subsections *Resistive Loading* and *Reactive Loading* in this section) when the input voltage is anywhere between 95 and 110 percent of the nominal value. The regulator is designed to withstand momentary voltages up to 120 percent of nominal input voltage without shutting off or being damaged by such overvoltage so long as the duration of overvoltage excursions are not longer than 50 milliseconds and do not occur more than once per minute.

2.18.7.1 Built-In True-rms-Reading Ammeter, L-828 only

For the L-828 only, a flush-mounted true-rms-reading ammeter mounted on the front of the input module PCB indicates the output current. The meter accuracy is ± 3.0 percent of the maximum output current.

2.18.8 Temperature Rise

The temperature rise of the transforming portion of the regulator is in accordance with ANSI C57.12.91 for air-cooled regulators.


2.19 Weights

Table 11: Weights

CCR	Weight - lb (kg)								
Size	208 V	220 V	230 V	240 V	347 V	380 V	400 V	480 V	600 V
2.5kW									
4kW	434 (196.9)	427 (193.7)		467 (211.8)				502 (227.7)	
5kW									
7.5kW	556 (252.2)	480 (217.7)		514 (233.1)				600 (272.2)	
10kW	783 (355.2)	749 (339.7)		770 (349.3)				826 (374.7)	
15kW	960 (435.4)	872 (395.5)		826 (374.7)				906 (411)	
20kW	1290 (585.4)	1150 (521.6)		1187 (538.4)				1097 (497.6)	
25kW									
30kW	1410 (639.6)	1350 (612.3)		1381 (626.4)				1302 (590.60)	

2.20 Dimensions

Figure 7: Ferroresonant CCR Dimensions – Typical of 2.5-30 kW



3.0 Installation

L-828 / L-829 CCR Installation



WARNING

Read installation instructions in their entirety before starting installation.

- Refer to the FAA Advisory Circular AC 150/5340-26, Maintenance of Airport Visual Aids Facilities, for instructions on safety precautions.
- Observe all safety regulations. To avoid injuries, always disconnect power before making any wiring connections or touching any parts.
- Become familiar with the general safety instructions in this section of the manual before installing, operating, maintaining or repairing this equipment.
- Read and carefully follow the instructions throughout this manual for performing specific tasks and working with specific equipment.
- Make this manual available to personnel installing, operating, maintaining or repairing this equipment.
- Follow all applicable safety procedures required by your company, industry standards and government or other regulatory agencies.
- Control PCB is static-sensitive. Must be grounded when handling PCB.
- Route electrical wiring along a protected path. Make sure they will not be damaged by moving equipment.
- Protect components from damage, wear, and harsh environment conditions.
- Allow ample room for maintenance, panel accessibility, and cover removal.
- Protect equipment with safety devices as specified by applicable safety regulations.
- If safety devices must be removed for installation, install them immediately after the work is completed and check them for proper functioning prior to returning power to the circuit.

This section provides instructions for installing L-828/L-829 constant current regulators (CCRs). Refer to the airport project plans and specifications for the specific installation instructions.

3.1 Unpacking

The equipment is shipped ready for installation. Handle equipment very carefully to prevent component damage. Unpack the carton upon receipt and check the contents and their condition. Note any exterior damage to the carton that might lead to detection of equipment damage.

If you note any damage to any equipment, file a claim with the carrier immediately. The carrier may need to inspect the equipment.

NOTE: Take care to maintain the unit in an upright position when handling the regulator.

3.2 Installation

The recommend lifting method for the regulators is to use a forklift from underneath the CCR frame. Lifting points, four 3/4-inch ID eyebolts on the top corners of the CCR frame, are provided per FAA specifications. If lifting eye bolts are used, use either a portable hoist and sling(s) or sling(s) attached from forks on forklift. See Table 11 (dimensions and weights) before lifting.



WARNING

Read installation instructions in their entirety before starting installation.

- If lift points (eyebolts) are used, lift straight up. Side loading on the eyebolts may cause them to bend.

Place the regulator inside a well ventilated room with sufficient clearance for personnel to inspect and maintain the unit.

3.2.1 Wiring Connections and Startup



WARNING


Read installation instructions in their entirety before starting installation.

- Installation and operation of the CCR should be performed by personnel qualified to work on high voltage equipment. The high voltage involved with the unit makes it potentially dangerous and may be lethal if contacted by operating personnel.
- Place wiring for output, input, and remote control only on the right side of the CCR to prevent damage to the PCB that is located on the front Left side of the enclosure. If output, input, and remote control wiring must enter from the left side of the enclosure then wiring must be then routed through conduit where it passes the PCB area.
See Figure 8.

To install wiring, perform the following procedure:

1. Verify the input supply voltage corresponds to the voltage rating on the nameplate of the regulator.
2. Make sure the front panel rotary selector switch is set to the OFF position.
3. Ground the regulator by making an adequate ground wire (AWG 6 or larger) connection to the external earth ground lug on the regulator.
4. An appropriate disconnect-type cutout or circuit breaker shall be provided outside the regulator for the input power supply lines.
5. Short-circuit the output terminals TB2-1, TB2-2 using 8 AWG minimum wire to avoid lamp destruction in case of excessive current output.
6. Refer to Table 4 for the recommended input wire. Connect the power supply lines from the disconnect switch or main circuit breaker to the CCR input fuse block F1/F2 or terminal block TB3. Tighten all connections.

Figure 8: Wiring on Right Side of CCR



1. Front of CCR
2. Place Conduit and Wire on Right Side of CCR

7. Engage main circuit breaker or disconnect switch to energize the regulator.
8. Turn front panel rotary selector switch to all brightness steps, and verify that current values on the panel ammeter correspond to those in Table 9 for each brightness step.
9. Disengage the main current breaker or disconnect switch to de-energize the regulator.
10. Turn the rotary selector switch to OFF.
11. Connect remote control lines, if required, to remote control terminal block TB1.
Use AWG 18, 300 V wire or larger for 120 Vac signals. See "Wiring Schematics" on page 59 for remote control connections.

NOTE: If the ADB Airfield Solutions Advanced Control Equipment (ACE) is used with the Ferroresonant L-828 CCR, refer to the Advanced Control Equipment manual (96A0245) or Advanced Control Equipment 2 (ACE2) manual (96A0357) for wiring connections to remote control.

Table 12 through Table 14 provide the necessary connections for the remote control (either 120 Vac or, +48Vdc). Terminal B1 (B10) does not need to be wired. Brightness step B1 (B10) occurs when the regulator is switched on.

Table 12: Remote Control Connections (3-Step/6.6 A)

For this remote intensity step...	Connect CCI to...
B10 (4.8 A)	CC
B30 (5.5 A)	CC, B30
B100 (6.6 A)	CC, B100
OFF	Not applicable

Table 13: Remote Control Connections (5-Step/6.6 A)

For this remote intensity step...	Connect CCI to...
B1 (2.8 A)	CC
B2 (3.4 A)	CC, B2
B3 (4.1 A)	CC, B3
B4 (5.2 A)	CC, B4
B5 (6.6 A)	CC, B5
OFF	Not applicable

Table 14: Remote Vac Control Connections (5-Step/20 A)

For this remote intensity step...	Connect CCI to...
B1 (8.5 A)	CC
B2 (10.3 A)	CC, B2
B3 (12.4 A)	CC, B3
B4 (15.8 A)	CC, B4
B5 (20 A)	CC, B5
OFF	Not applicable

12. Make sure wiring connections are tight and no wires are shorting across each other.



CAUTION

Read installation instructions in their entirety before starting installation.

- Incorrect wiring can damage regulator. Double check all connections.

13. Energize regulator and set rotary selector switch to REM. Operate the CCR by remote control, and verify correct current levels are obtained on all brightness steps.

14. Turn rotary selector switch to OFF and de-energize regulator (disengage disconnect switch or main circuit breaker). Remove short-circuit link between output terminals TB-2-1 and TB2-2.


15. Connect the 6.6 A or 20 A series lighting circuit to the output terminals/ bushings and tighten all connections.

Table 15: Input/Output Connections

CCR Size	Input Location	Output Location
2.5 thru 30kW with SCO	Top of each Fuse Block front of component plate right hand side	Bottom of SCO
CSF 20kW/208 V		Lightning Arrestors (VR1 and VR2) on Back of component plate
CSF 30kW/208 V		
CSF 2.5, 4, 5, 7.5, 10 kW	Terminal Block (black)	Lightning Arrestors (VR1 and VR2) on Back of component plate
	Front of component plate right hand side	
CSF 15, 20, 25, 30 kW	Terminal Block (white)	Lightning Arrestors (VR1 and VR2) on Back of component plate
	Front of component plate right hand side Top of each Fuse Block front of component plate right hand side	

3.3 Frames

Figure 9: CSF CCR Assembly



4.0 Operation



WARNING

Read the instructions in their entirety before starting installation.

- Contents are static-sensitive. Must be grounded when handling PCB.
- Operation of a Regulator while overloaded at any step may result in equipment failure or equipment damage.

4.1 Introduction

This section provides the operational procedures listed below for the L-828/L-829 constant current regulator (CCR).

- CCR control procedures
- CCR shutdown procedures
- CCR adjustment procedures
- SCO Cutout working positions

4.2 CCR Control Procedures

4.2.1 Local Control

This subsection describes the regulator operations in local and remote controls.

See Figure 10. Refer to Table 16 through Table 18 for output current when using local control. The front panel rotary selector switch is used for regulator local control. The rotary switch for the 3-step CCR has five positions; the rotary switch for the 5-step has seven positions. The regulator automatically maintains the output current within $\pm 1\%$ of the nominal value for the brightness position selected.

Figure 10: Switch (3-Step/5-Step)




Table 16: Output Current from Rotary Switch (3-Step/6.6A)

If you set the rotary switch to the following...	The result is...
B10	4.8 A current output
B30	5.5 A current output
B100	6.6 A current output

Table 17: Output Current from Rotary Switch (5-Step/6.6 A)

If you set the rotary switch to the following...	The result is...
B1	2.8 A current output
B2	3.4 A current output
B3	4.1 A current output
B4	5.2 A current output
B5	6.6 A current output

Table 18: Output Current from Rotary Switch (5-Step/20 A)

If you set the rotary switch to the following...	The result is...
B1	8.5 A current output
B2	10.3 A current output
B3	12.4 A current output
B4	15.8 A current output
B5	20 A current output

4.2.2 Remote Control

See Figure 10. Refer to Table 19 for instructions on how to set up and use remote control.

Table 19: Remote Control

If...	Then...
The rotary switch is set to position REM and remote control wiring is connected to remote control terminal block TB1 on the regulator	Remote control of the regulator is possible. The output current of the regulator will correspond to the brightness setting energized by remote 120 Vac or 48 Vdc control signals.
Switch is set to OFF	Remote control signals will not operate the regulator; that is, turn the regulator on to a particular brightness setting or turn the regulator off.
No remote control connections exist on terminal block TB1 (switch is set to REM)	The position REM becomes an additional OFF position; that is, the regulator is de-energized.

4.3 CCR Door Interlock

The door interlock disables remote and local control of the CCR when the door is opened. If the door is opened while the CCR is running, the CCR will shut OFF.

This is to protect personnel from coming into contact with high voltage electronics.

NOTE: Power to the output terminals is now off, and the regulator cannot be energized by remote control signals. **Power is still present on the input power terminals and on the internal control circuitry.**

To bypass the interlock, pull out the plunger of the interlock switch. This will allow remote and local control of the CCR with the door open.

4.4 CCR Shutdown Procedure

See Figure 10. To shut down the CCR, set the rotary switch to position OFF.

The door interlock removes power to the CCR when the door is opened. Pull out the plunger fully to bypass.

NOTE: Power to the output terminals is now off, and the regulator cannot be energized by remote control signals. Power is still present on the input power terminals and on the internal control circuitry.

To remove input power, disengage disconnect switch or external circuit breaker.

4.5 CCR Adjustment Procedures

This subsection provides regulator adjustment procedures.

NOTE: The regulator has been adjusted at the factory to provide the nominal output current levels as given in Table 16. If the current level settings need to be adjusted, read the following warning statement before proceeding.



WARNING

Read the instructions in their entirety before starting installation.

Only personnel qualified to work on high voltage systems should attempt to make any adjustments on the constant current regulator.

Turn the rotary selector switch on the front panel of the regulator to position OFF. Remove input power before servicing control circuitry.


Never service the regulator when it is in protective shutdown mode, Remote controls or power fluctuations can restart the regulator.

4.5.1 Output Current Adjustment

To adjust the output current, perform the following procedure:

1. Connect a clamp-on true rms-reading instrument (such as a Fluke 87 multimeter with a current clamp) around one of the output current leads. See Figure 11.
2. If the optional current clamp test point is present the clamp-on instrument on the CCR component plate should be utilized.

Figure 11: Output Current Clamp




NOTE: Make sure the meter is set on the AC current scale.

Because the output current waveform is not a true sine wave, the ammeter must be of the true-rms (root mean squared) type. Field instruments such as clamp-on ammeters and Simpson voltmeters will give erroneously low readings.

4.5.2 Adjusting Output Current

Figure 12: Regulator Control PCB (44A7293)



To adjust the output current of Regulator Control Board, perform the following procedure:

1. For 3-step operation, verify that the jumper is in place between J5 pins 5 and 6, (Figure 12 item 1). No jumper is required for 5-step operation.
2. Turn on the CCR and set local control switch to the highest intensity step, B5 for 5-step CCR, B100 for a 3-step CCR.
3. The external True-RMS ammeter should read 6.60 ± 0.1 amps. If the reading is outside of this range, adjust the output current with buttons INC and DEC (Figure 12, Item 2) on the Control PCB until the correct current is obtained. Press and hold the SAVE button (Figure 12, Item 3) for two seconds to save the setting.
4. Turn off the CCR. Remove the short from the output and apply the field load.
5. Again, turn on the CCR and set local control switch to the highest intensity step, B5 for 5-step CCR, B100 for a 3-step CCR.
6. The external True-RMS ammeter should read 6.60 ± 0.1 amps. If the reading is outside of this range, adjust the output current with buttons INC and DEC (Figure 12, Item 2) on the Control PCB until the correct current is obtained. Press and hold the SAVE button (Figure 12, Item 3) for two seconds to save the setting.

NOTE: Each CCR output current step is independently adjustable and must be independently saved.

7. Set the local switch to next to the lowest brightness step, and verify that the True-RMS ammeter reading corresponds to Table 16 thru Table 18.
8. If the reading is not in the current value range given in the Tables, adjust the appropriate step until the correct current value is obtained.
9. Repeat Step 2 for the remaining lower brightness step(s).
When the output current adjustment has been completed, turn off the CCR.

4.5.2.1 Adjusting Overcurrent Control Board

Adjusting the CCR over current detection level

Before adjusting the Over Current Detection level, set up the regulator and adjust the output current per the **ADJUSTING THE CCR OUTPUT CURRENT** section of this section.

NOTE: The Over Current setting is pre-set and should normally not need adjusted.

To adjust the overcurrent, perform the following procedure:

1. Short the output of the CCR so the field load cannot be damaged by an over current situation during the adjustment.
2. Turn the local switch to the highest brightness step, B5 for 5-step CCR, B100 for a 3-step CCR. The true-RMS ammeter should read 6.6 amps.
3. Press and hold for three seconds both the INC and DEC buttons (Figure 12, Item 2). The SAVE LED (Figure 12, Item 4) will light when you are in the Over Current Adjustment Mode.


NOTE: The CCR output current will increase to the level previously set as the Over Current level. This will be above 6.6 amps.

4. Press the INC or DEC buttons (Figure 12, Item 2) until you reach the desired Over Current detection level.
5. Press and hold the SAVE button for two seconds. The SAVE LED (Figure 12, Item 4) will go out and the CCR output will go back to the top step setting of 6.6 amps.
6. Remove the short from the CCR output and apply the field load.

4.6 SCO Cutout Working Positions

See Figure 13. The SCO cutout can be plugged in three orientations. For additional information on the SCO cutout, refer to manual 96A0294, *SCO Cutout*.


Figure 13: Handle Orientations



In the operation position, the regulator is connected to the series circuit, and the microswitch is activated.


NOTE: An activated microswitch means that the normally open contact is closed and that the normally closed contact is open. For interlocking with the CCR, only the normally open contact is used. When the cover is removed, the microswitch is not activated. When the microswitch is not activated local and remote control is disabled.

Figure 14: SCO Cutout Operation Position



See Figure 15. In the maintenance position, the regulator and the series circuit are both shorted and grounded. The microswitch is not activated.

Figure 15: SCO Cutout Maintenance Position




You can determine the current orientation by observing the cutoff corner of the handle.

See Figure 16. In the test and measure position, the insulation resistance of the series circuit can be measured. The regulator operation can be tested under short-circuited output conditions.

In the test and measure position, the regulator is shorted and grounded; the series circuit is shorted and connected to the measurement socket. The microswitch is activated.

Figure 16: SCO Cutout Test and Measure Position



4.7 Application Notes

Monitoring Option	Description	Application
0	None	Standard L-828 supplied with analog ammeter
3	L-829 Monitoring (ACE™)	Includes FAA L-829 monitoring equipment. <ul style="list-style-type: none"> If application is for connection to ADB L-890 ALCMS: Add a “/A” to end of Ordering Code. The ACE unit will then be programmed to provide monitoring data via dual-redundant communication links. If application is for a stand-alone L-829 CCR: Ordering Code is not changed. The ACE unit is programmed to activate a dry contact closure if a fault is present. The fault alarm can then be connected to any external monitoring system.
4	Insulation Resistance Monitoring System (IRMS) Ready	This option adds an IRMS board in the CCR. Application: connection to externally mounted ADB ACE unit.
5	L-829 Monitoring (ACE) and IRMS	Includes FAA L-829 and IRMS equipment. <ul style="list-style-type: none"> If application is for connection to ADB L-890 ALCMS: Add a “/A” to end of Ordering Code. The ACE unit will then be programmed to provide monitoring data via dual-redundant communication links. If application is for a stand-alone L-829 CCR with Insulation Resistance Monitoring: Ordering Code is not changed. The ACE unit is programmed to activate a dry contact closure if a fault is present. The fault alarm can then be connected to any external monitoring system.
6	L-828 with Digital Power Meter	This option replaces the analog ammeter with a Digital Power Meter. The Digital Power Meter is used on L-828 CCRs to indicate True RMS output current, voltage, VA, and watts. It can also be set to activate an alarm if there is a 10% or 15% drop in the load (Low VA).

4.8 Digital Power Meter Calibration (optional)


4.8.1 Display

Figure 17: Meter Display




4.8.2 Function Buttons

Figure 18: Function Buttons



4.8.3 DPM Displays



NOTE: Scroll through displays using the **Scroll Up** and **Scroll Down** buttons. After 30 seconds the display will revert to the default setting of **A rms**.

4.8.4 Calibration Procedure

NOTE: The following is needed to calibrate the DPM:

- Calibrated true-rms AC multimeter with current clamp.
- High Voltage probe capable of reading 5,000V true-rms.
- Ability to apply a shorted load to CCR.
- Ability to apply a field load or equivalent resistive load to CCR.



WARNING


Read the instructions in their entirety before starting installation.

The CCR must be operating during calibration. Risk of electrical shock. Failure to observe this warning may result in personal injury, death, or equipment damage.

Proceed as follows to calibrate the DPM

1. Depress and hold the top **SCROLL** button and the bottom **ENTER** button **simultaneously** for 3 seconds (See Figure 18) to enter the calibration menu.

Figure 19: Calibration Menu



The **SCROLL** buttons are used to select items on the calibration menu. Scroll to the desired selection and then press the **ENTER** button. See the following steps to calibrate the DPM.

Current Calibration

During calibration you will be asked to wait until displayed “cnt” values settle. These “cnt” values are internal A/D values as measured by the power meter’s microprocessor. These values will always vary slightly while the meter is measuring voltage and current. They are displayed to give feedback that the load has settled and the meter is obtaining a steady reading.

NOTE: TIP: At each calibration step, wait until the thousands digit has settled before proceeding.

A. Irms – High Step (6.6 amps)

Using the **SCROLL** buttons, select **Irms** and follow the prompts to calibrate the **Irms**.

- Short the CCR output and then turn the CCR to the highest step.
- Measure the CCR output current with a true-rms current meter and adjust the current value on the meter display to match.

NOTE: If the CCR output needs to be adjusted follow the procedure in “CCR Adjustment Procedures” on page 24.

- Wait until the **Irms** and **V Cnt** values settle and select the **ENTER** button.

Figure 20: Irms High Step Calibration



B. Irms Low Step (2.8 amps)

Repeat the previous steps and follow the prompts for the Low CCR step.

C. Press **ENTER** button to save.


Figure 21: Irms Low Step Calibration



Voltage Calibration

At the calibration screen, scroll to Vrms on the menu and press the **ENTER** button. The next screen (Figure 22) shows the last calibration voltage set points and internal A/D numbers. **Select Y** (yes) to enter the Vrms calibration.

Figure 22: Vrms Calibration



A. Vrms – High Step Loaded




WARNING

Read the instructions in their entirety before starting installation.
Use proper safety procedures when adjusting the meter display.

Following screen prompts, apply the field load or equivalent resistive load to the CCR at the high step. Measure the Vrms at the CCR output terminals with the High Voltage probe. Adjust the meter display to match the measured voltage. Wait for the cnt-number to settle (this may take a couple minutes while the load heats up) and then press the **ENTER** button.


Figure 23: Vrms High Step Loaded



B. Vrms - Off

Follow the prompts to turn off the CCR. When the **Cnt** has settled press the **ENTER** button.
(**Cnt** may not go to zero)

Figure 24: Save Vrms Calibration



5.0 Maintenance and Repair

This section provides maintenance and repair instructions for the L-828 and L-829 CSF Air-cooled CCRs.



WARNING

Read the instructions in their entirety before starting installation.

- Only personnel authorized to work on high-voltage equipment should perform maintenance on the regulator.
- Operate regulator under local control (using rotary switch) when performing maintenance tasks on the regulator. This will prevent the regulator from accidentally being turned on and causing serious injury or death. De-energize regulator by turning rotary switch to OFF, and remove input power to regulator by turning off disconnect switch or main circuit breaker before opening access door to service regulator.
- If the regulator experiences an overvoltage or an over-current fault, it will enter protective shutdown mode. In this mode, the regulator turns off until either power to the regulator is cycled, or the regulator is turned off with either the rotary switch or the remote controls.

This section provides preventive maintenance for L-828 /L-829 constant current regulators (CCRs).

5.1 Maintenance Schedule

To keep the L-828/L-829 CCRs operating efficiently, follow a preventive maintenance schedule. Refer to Table 20.

Table 20: L-828/L-829 CCR Maintenance

Interval	Maintenance Task	Action
Daily	Check all control equipment for proper operation.	Check local and remote control (if used) on each brightness step.
Monthly	Check input voltage.	If input voltage is not within -5% to +10% of the nominal value specified on the nameplate of the regulator, notify power company to correct voltage.
	Check and record output current on each brightness step.	Use a true-rms reading instrument. Adjust current levels if out of tolerance. Refer to <i>Adjustment Procedures</i> in the <i>Operation</i> section. Refer to "Output Current and Limits" on page 12 for the current range for the 3-Step and 5-Step CCRs.
Annually	Check relays, wiring and insulation.	Replace contacts that are excessively burned or pitted.
		Operate the local control switch to check for proper operation of relays and contactors.
		Make sure input and output connections are tight and that no damaged wires or damaged insulation exists.
	Inspect housing for rust spots.	Clean and touch-up rust spots with paint.
	Inspect lightning arrestor connections.	Tighten any loose connections. Replace charred or burnt wiring or broken arrestors.
	Perform a short-circuit test.	Refer to <i>Short-Circuit Test</i> in this section.
Unscheduled	Check load on regulator.	Refer to <i>Open-Circuit Test</i> in this section.
		At installation and subsequent load changes make sure that the output rms-voltage times the output true-rms current does not exceed the rated load on the nameplate of the regulator.

5.1.1 Short-Circuit Test



WARNING

Read the instructions in their entirety before starting installation.

Only personnel authorized to work on high-voltage equipment should perform maintenance on the regulator.

Since high open-circuit voltages may result by opening the primary of a series lighting circuit, only personnel authorized to work on high-voltage equipment should be allowed to perform the short-circuit test.

To perform the short-circuit test, perform the following procedure:

1. Remove input power to the regulator (turn off disconnect switch or main circuit breaker) and turn the rotary switch to OFF.
2. Remove leads from output terminals and bushings. Use AWG 8 or larger wire to short output bushings.
3. Energize the regulator and turn the rotary selector switch to the lowest brightness step (1) and then to the remaining brightness steps. Check the output current on the ammeter at each step.

NOTE: The output current should be within the tolerance given in "Output Current and Limits" on page 12. The panel meter is intended to indicate function. Any calibrations should be performed with a calibrated true-rms current meter.

4. If the output current is not within the limits specified in "Output Current and Limits" on page 12 check the input voltage to the regulator. The supply voltage should be within -5% to +10% of the nominal input voltage given on the regulator nameplate. Refer to *Adjustment Procedures* in the *Operation* section.
5. Turn off disconnect switch or main circuit breaker to remove input power to regulator.
6. Disconnect the shorting jumper and reconnect output cables.
7. Close input-power disconnect switch or main circuit breaker.

5.1.2 Open-Circuit Test



WARNING

Read the instructions in their entirety before starting installation.

Only personnel authorized to work on high-voltage equipment should perform maintenance on the regulator.

Since high open-circuit voltages may result by opening the primary of a series lighting circuit, only personnel authorized to work on high-voltage equipment should be allowed to perform the open-circuit test.

To perform the open-circuit test, perform the following procedure:

1. Remove input power to regulator (turn off disconnect switch or main circuit breaker) and turn the rotary switch to OFF.
2. Disconnect cables from the output terminals and bushings.
3. Turn on input power to the regulator.
4. Turn the rotary switch to the lowest brightness position (1). The open-circuit protective device should automatically de-energize the regulator in less than 2 seconds.
5. Turn the rotary switch to OFF. The open-circuit protective device should reset.
6. Turn the rotary switch to position 1. The regulator should turn on and then de-energize in less than 2 seconds.
7. If regulator operation is satisfactory, turn rotary switch to OFF, and turn off disconnect switch or main circuit breaker before reconnecting the load.
8. After the load has been reconnected, turn on input power to the regulator.

5.2 Troubleshooting



WARNING

Read the instructions in their entirety before starting installation.

- Only personnel authorized to work on high-voltage equipment should perform maintenance on the regulator.
- Allow only qualified personnel to perform the following tasks. Observe and follow the safety instructions in this document and all other related documentation.
- Since high open-circuit voltages may result by opening the primary of a series lighting circuit, only personnel authorized to work on high-voltage equipment should be allowed to perform the open-circuit test.
- De-energize regulator by turning rotary switch S1 to OFF, and remove input power to regulator by turning off disconnect switch or main circuit breaker. Discharge capacitors and ground output terminals bushings by using a grounding rod prior to touching any parts.
- If the regulator de-energizes, the output circuit could be interrupted by an overcurrent, open-circuit, or undervoltage condition. Before inspecting the output circuit. Place rotary selector switch S1 in the OFF position and turn off disconnect switch or main circuit breaker. Without this precaution, a dip in the power line may reset the regulator and turn it on, resulting in an output voltage of thousands of volts which can cause serious injury or death.
- The control board is static-sensitive. The PCB must be grounded when handling.
- Short the output terminals before switching the regulator on. The wire should be AWG 8 or larger.

5.2.1 Preliminary Troubleshooting

The following is a check list of initial steps to perform.

- Visually examine all areas of the CCR. Do burnt or loose connections/parts exist?
- Is the input voltage present and within +10 to -5% of nominal?
- Check all the fuses.
- Are the wire harness connectors to the control board fully seated?
- Have the PCBs been adjusted in accordance with the instruction manual?
- If the CCR works in local but not Remote, check the voltage on the Remote control lines.
- Can the CCR be re-energized by turning the rotary switch from OFF to Step B1 (B10)?
- Short the output of the CCR with an AWG 8 wire, and turn on the CCR. If the regulator operates normally, the problem is probably load related.
- If the CCR turns on and then shuts off after a few seconds and the ammeter has a high current reading, the problem is overcurrent. Adjust the output current accordingly. If the output current is not adjustable, replace the control board restart the regulator.
- If the CCR still fails in overcurrent, replace the SCR and restart.

5.2.2 Troubleshooting
Control Board

Figure 25: The Control Board




Table 21: Diagnostic LEDs on the Control Board

LED	Indication	Description
D9	Heartbeat	Will flash continuously in normal operation
D8	SCR Failure	Indicates that the SCR has failed
D7	Output Overload	CCR is overloaded
D6	Output Open Circuit	CCR has detected an open circuit
D5	Output Over Current	CCR has detected and over current condition
D10	Save	Indicates the step current has been saved during calibration

Table 22: Remote Input Status

LED	Indication	Description
D11	ON	CC is active
D12	ON	B5 is active
D13	ON	B4 is active
D14	ON	B3/B100 is active
D15	ON	B2/B30 is active

5.2.3 Troubleshooting Fuses

This subsection provides information for troubleshooting fuses.

Table 23: L-828/L-829 Input Power Fuses F1 and F2.

Amp rating as a function of input voltage and CCR kW rating for input power fuses F1 and F2 on the L-828 and L-829 CCRs. Input Power Fuses, F1 and F2, per CCR Input Voltage and CCR kW Rating

SIZE	208	220	230 V	240 V	347 V	380 - 400 V	480 V	600 V
2.5 kW	47A0228	47A0228		47A0175	47A0223	47A0223	47A0226	47A0222
4 kW	47A0092	47A0092	47A0069	47A0069	47A0191	47A0191	47A0090	47A0223
5 kW	47A0229	47A0229		47A0092	47A0191	47A0191	47A0190	47A0090
7.5 kW	47A0093	47A0093		47A0070	47A0193	47A0085	47A0091	47A0191
10 kW	47A0094	47A0094	47A0071	47A0071	47A0086	47A0086	47A0085	47A0091
15 kW	47A0099	47A0099	47A0096	47A0083	47A0087	47A0087	47A0088	47A0086
20 kW	47A0230	47A0072	47A0072	47A0072	47A0097	47A0217	47A0087	47A0224
25 kW	47A0101	47A0101		47A0230	47A0227	47A0097	47A0217	47A0087
30 kW	47A0102	47A0102	47A0101	47A0101	47A0106	47A0106	47A0097	47A0225

PART NUMBER	DESCRIPTION
47A0069	Fuse 25A, 250V Time Delay
47A0070	Fuse 45A, 250V
47A0071	Fuse 60A, 250V
47A0072	Fuse 125A, 250V
47A0083	Fuse 90A, 250V
47A0085	Fuse 30A, 600V
47A0086	Fuse 40A, 600V
47A0087	Fuse 60A, 600V
47A0088	Fuse 50A, 600V
47A0090	Fuse 12A, 600V
47A0091	Fuse 25A, 600V
47A0092	Fuse 30A, 250V
47A0093	Fuse 50A, 250V
47A0094	Fuse 70A, 250V
47A0096	Fuse 80A, 250V
47A0097	Fuse 90A, 600V
47A0099	Fuse 110A, 250V
47A0101	Fuse 175A, 250V
47A0102	Fuse 200A, 250V
47A0106	Fuse 125A, 600V
47A0175	Fuse 15A, 250V
47A0190	Fuse 17A, 600V
47A0191	Fuse 20A, 600V
47A0193	Fuse 35A, 600V
47A0217	Fuse 80A, 600V
47A0222	Fuse 6A, 600V
47A0223	Fuse 10A, 600V
47A0223	Fuse 10A, 600V
47A0224	Fuse 45A, 600V

PART NUMBER	DESCRIPTION
47A0225	Fuse 70A, 600V
47A0226	Fuse 8A, 600V
47A0227	Fuse 100A, 600V
47A0228	Fuse 20A, 250V
47A0229	Fuse 35A, 250V
47A0230	Fuse 150A, 250V

Table 24: Input Fuse Blocks

SIZE	208 V	220 V	230 V	240 V	347 V	380 - 400 V	480 V	600 V
2.5 kW	72A0091	72A0091	72A0091	72A0091	49A0081	49A0081	49A0081	49A0081
4 kW	72A0091	72A0091	72A0091	72A0091	49A0081	49A0081	49A0081	49A0081
5 kW	72A0098	72A0098		72A0091	49A0081	49A0081	49A0081	49A0081
7.5 kW	72A0098	72A0098	72A0098	72A0098	49A0082	49A0081	49A0081	49A0081
10 kW	72A0091	72A0091		72A0098	49A0082	49A0082	49A0081	49A0081
15 kW	72A0099	72A0099		49A0091	49A0085	49A0085	49A0082	49A0082
20 kW	72A0099	72A0099	72A0099	72A0099	49A0085	49A0085	49A0082	49A0082
25 kW	72A0099	72A0099	72A0099	72A0099	49A0085	49A0085	49A0085	49A0082
30 kW	72A0099	72A0099	72A0099	72A0099	49A0097	49A0097	49A0085	49A0085

PART NUMBER	DESCRIPTION
49A0081	Fuse Block, 10-30A, 600V
49A0082	Fuse Block, 31-60A, 600V
49A0085	Fuse Block, 61-100A, 600V
49A0097	Fuse Block, 100-200A, 250V
72A0091	Fuse Block, 2P, 30A, 250V
72A0098	Fuse Block, 31-60A, 250V
72A0099	Fuse Block, 100-200A, 250V

Table 25: L-828 / L-829 Step-Down T4 Transformer Fuses F3 and F4

Fuses F3 and F4 on the L-828/L-829 CCRs protect transformer T4, which supplies 110 Vac and 24 Vac to the universal regulator control card. Transformer T3 Fuses F3 and F4 Ratings

SIZE	208-347 V	380 V	400 V	480 V	600 V
2.5 kW				47A0108	
4 kW	47A0113			47A0108	
5 kW	47A0113			47A0108	
7.5 kW	47A0113			47A0108	
10 kW	47A0113			47A0108	
15 kW	47A0187	47A0187	47A0187	47A0187	
20 kW	47A0187	47A0187	47A0187	47A0187	
25 kW	47A0187	47A0187	47A0187	47A0187	
30 kW	47A0187	47A0187	47A0187	47A0187	

PART NUMBER	DESCRIPTION
47A0108	Fuse 1A 500V
47A0113	Fuse 2A 250V
47A0187	Fuse 3A 500V
49A0084	Fuse Holder (Double) (4, 20-30 kW)

Table 26: L-829 Power Supply Transformer Fuse F5 and ACE Power Supply Fuse F6
Universal regulator power supply transformer fuse F5 protects the remote control circuitry on the URC. Fuse F6 protects the 120 Vac power supply to the ACE. Fuses F5 and F6 Ratings

CSF/XXXX ACE Fuses F5, F6

47A0119	Fuse .5A 250V
47A0061	Fuse Block (single)

Table 27: 44A7293 Control Board Fuses F1, F2, F3

PART NUMBER	DESCRIPTION
47A0017	Fuse 1A, 250V Slow Blow (3AG)

Table 28: Current Transformer T2

6.6 A	20 A
35A0263	35A0308

35A0263 Current Transformer 6.6/6.6A (Only required if analog current meter used)

35A0308 Current Transformer 20/6.6A (Only required if analog current meter used)

Table 29: CSF CCR Contactors

SIZE	208-240 V	347 V	380 - 400 V	480 V	600 V
2.5 kW	53A0412/25	53A0412/25	53A0412/25	53A0412/25	53A0412/25
4 kW	53A0412/30	53A0412/25	53A0412/25	53A0412/25	53A0412/25
5 kW	53A0412/40	53A0412/25	53A0412/25	53A0412/25	53A0412/25
7.5 kW	53A0412/50	53A0412/40	53A0412/40	53A0412/40	53A0412/25
10 kW	53A0412/70	53A0412/40	53A0412/40	53A0412/40	53A0412/25
15 kW	53A0412/120	53A0412/60	53A0412/60	53A0412/50	53A0412/40
20 kW	53A0412/150	53A0412/90	53A0412/90	53A0412/60	53A0412/50
25 kW	53A0412/150	53A0412/90	53A0412/90	53A0412/90	53A0412/60
30 kW	53A0331	53A0412/150	53A0412/150	53A0412/90	53A0412/75

PART NUMBER	DESCRIPTION
53A0331	Contactactor 3P 200A 170A 120VAC Coil
53A0412/120	Contactactor 2P 120 FLA
53A0412/150	Contactactor 2P 150 FLA
53A0412/175	Contactactor 2P 175 FLA
53A0412/25	Contactactor 2P 25 FLA
53A0412/30	Contactactor 2P 30 FLA
53A0412/40	Contactactor 2P 40 FLA
53A0412/50	Contactactor 2P 50 FLA
53A0412/60	Contactactor 2P 60 FLA
53A0412/70	Contactactor 2P 70 FLA
53A0412/75	Contactactor 2P 75 FLA
53A0412/90	Contactactor 2P 90 FLA

Table 30: Dual SCR Blocks

SIZE	208 - 600 V
2.5 kW	28A0056
4 kW	28A0056
5 kW	28A0056
7.5 kW	28A0056
10 kW	28A0056
15 kW	28A0057
20 kW	28A0055
25 kW	28A0054
30 kW	28A0054

PART NUMBER	DESCRIPTION
28A0054	Dual SCR Module (25 - 30 kW)
28A0055	Dual SCR Module (20 kW)
28A0056	Dual SCR Module (2.5 - 10 kW)
28A0057	Dual SCR Module (15 kW)

Table 31: Input Lightning Arrestor VR7, VR8

CSF/XXXX Input Lightning Arrestor VR7, VR8

32A0028	Input Power Lightning Assestor (All sizes and input voltages)
	(Kit used is 94B0011)

Table 32: CSF/XXXX Output Lightning Arrestor VR1, VR2 (6.6 Amp)

SIZE	208-600 V
2.5 kW	32A0115
4 kW	32A0115
5 kW	32A0115
7.5 kW	32A0115
10 kW	32A0115
15 kW	32A0114
20 kW	32A0114
25 kW	32A0114
30 kW	32A0114
PART NUMBER	DESCRIPTION
32A0114	Surge Arrestor 6kV (Kit is 94A0433-6)
32A0115	Surge Arrestor 3kV (Kit is 94A0433-3)

Table 33: CSF/XXXX Output Lightning Arrestor VR1, VR2 (20 Amp)

SIZE	208-400 V	480-600 V
15 kW	94A0433-3	94A0433-6
20 kW	94A0433-3	94A0433-6
25 kW		94A0433-6
30 kW	94A0433-6	94A0433-6
PART NUMBER	DESCRIPTION	
94A0433-3	Surge Arrestor Kit 3kV (32A0115)	
94A0433-6	Surge Arrestor Kit 6kV (32A0114)	

Table 34: CSF/XXXX Current Sensing Transformer (T5)

CSF/XXXX Current Sensing Transformer (T5)

SIZE		
6.6A	35A0548	Transformer, Current Sensing, 6.6A to 66mA
20A	35A0528	Transformer, Current Sensing, 20A to 66mA

Table 35: CSF/XXXX Power Transformer (T4)

PART NUMBER	DESCRIPTION
35A0539	240/347/480 to 120/24 .5A (2.5 - 10 kW)
35A0546	240/347/480 to 120/24 .5A (15 - 30 kW)

Table 36: CSF/XXXX Other Parts

PART NUMBER	DESCRIPTION
44A7293-00	CSF Control Board
44A6397	IRMS-LI Board (Option)
44A6178	Rotary Switch (3 Step)
44A6178-5	Rotary Switch (5 Step)
1475.92.030	SCO Series Circuit Cutout (Option)
70A0624	Fiber Optic Cable (M-M) (Grey) (Option with ACE)
70A0625	Fiber Optic Cable (M-M) (Blue) (Option with ACE)
42A0525-3	Rotary Switch Label (3 Step)
42A0525-5	Rotary Switch Label (5 Step)
94A0425	Digital Power Meter Kit (Option)
45A0303	Door Interlock Switch

Table 37: Current / Voltage Monitor Assembly (CVM)

CSF/XXXX Current / Voltage Monitor Assembly (CVM) (Option)	
44A6326/10	Current / Voltage Monitor Assembly (6.6A)
44A6326/11	Current / Voltage Monitor Assembly (20A)

Table 38: Ammeters

CSF/XXXX Ammeter	
52A0099	Analog Ammeter (6.6A)
52A0098	Analog Ammeter (20A)

Note: Refer to ACE Manuals for Optional L-829 Monitoring and Control

Table 39: CSF/XXXX Capacitor Plate Assembly (6.6 A 60 Hz)

SIZE	208 - 480 V	600 V
2.5 kW	44A7306/026	
4 kW	44A7306/046	
5 kW	44A7306/056	
7.5kW	44A7306/076	
10 kW	44A7306/106	
15 kW	44A7306/156	
20 kW	44A7306/206	
25 kW	44A7306/256	
30 kW	44A7306/306	

PART NUMBER	DESCRIPTION	CAPACITOR 68 µF 525V	CAPACITOR 34 µF 525V
44A7306/026	Capacitor Plate (2.5 kW, 6.6 A, 60 Hz)	1	1
44A7306/046	Capacitor Plate (4 kW, 6.6 A, 60 Hz)	2	0
44A7306/076	Capacitor Plate (7.5 kW, 6.6 A, 60 Hz)	3	1
44A7306/106	Capacitor Plate (10 kW, 6.6 A, 60 Hz)	4	1
44A7306/156	Capacitor Plate (15 kW, 6.6 A, 60 Hz)	6	1
44A7306/206	Capacitor Plate (20 kW, 6.6 A, 60 Hz)	9	0
44A7306/256	Capacitor Plate (25 kW, 6.6 A, 60 Hz)		
44A7306/306	Capacitor Plate (30 kW, 6.6 A, 60 Hz)	12	1

Table 40: CSF/XXXX Capacitor Plate Assembly (6.6 A 50 Hz)

SIZE	220 - 400 V
2.5 kW	44A7306/025
4 kW	44A7306/045
5 kW	44A7306/055
7.5kW	44A7306/075
10 kW	44A7306/105
15 kW	44A7306/155
20 kW	44A7306/205
25 kW	44A7306/255
30 kW	44A7306/305

PART NUMBER	DESCRIPTION	CAPACITOR 68 µF 525V	CAPACITOR 34 µF 525V
44A7306/025	Capacitor Plate (2.5 kW, 6.6 A, 50 Hz)		
44A7306/045	Capacitor Plate (4 kW, 6.6 A, 50 Hz)	3	0
44A7306/075	Capacitor Plate (7.5 kW, 6.6 A, 50 Hz)		
44A7306/105	Capacitor Plate (10 kW, 6.6 A, 50 Hz)	5	0
44A7306/155	Capacitor Plate (15 kW, 6.6 A, 50 Hz)	8	0
44A7306/205	Capacitor Plate (20 kW, 6.6 A, 50 Hz)	10	1
44A7306/255	Capacitor Plate (25 kW, 6.6 A, 50 Hz)		
44A7306/305	Capacitor Plate (30 kW, 6.6 A, 50 Hz)	14	1

Table 41: CSF/XXXX Power Transformer T1 (6.6 Amp, 60 Hz Core)

SIZE	208, 220, 240 V 6.6 A	347, 380 V 6.6 A	480 V 6.6 A	600 V 6.6 A
2.5 kW	35A0774/11	35A0774/31	35A0774/31	35A0774/41
4 kW	35A0775/11	35A0775/31	35A0775/31	35A0775/41
5 kW	35A0794/11	35A0794/31	35A0794/31	35A0794/41
7.5 kW	35A0776/11	35A0776/31	35A0776/31	35A0776/41
10 kW	35A0777/11	35A0777/31	35A0777/31	35A0777/41
15 kW	35A0778/11	35A0778/31	35A0778/31	35A0778/41
20 kW	35A0779/11	35A0779/31	35A0779/31	35A0779/41
25 kW	35A0795/11	35A0795/31	35A0795/31	35A0795/41
30 kW	35A0780/11	35A0780/31	35A0780/31	35A0780/41

PART NUMBER	DESCRIPTION
35A0774/11	CSF Power Transformer, 2.5 kW 6.6A 208 220 240V
35A0774/21	CSF Power Transformer, 2.5 kW 6.6A 347 380V
35A0774/31	CSF Power Transformer, 2.5 kW 6.6A 480V
35A0774/41	CSF Power Transformer, 2.5 kW 6.6A 600V
35A0775/11	CSF Power Transformer, 4 kW 6.6A 208 220 240V
35A0775/21	CSF Power Transformer, 4 kW 6.6A 347 380V
35A0775/31	CSF Power Transformer, 4 kW 6.6A 480V
35A0775/41	CSF Power Transformer, 4 kW 6.6A 600V
35A0776/11	CSF Power Transformer, 7.5 kW 6.6A 208 220 240V
35A0776/21	CSF Power Transformer, 7.5 kW 6.6A 347 380V
35A0776/31	CSF Power Transformer, 7.5 kW 6.6A 480V
35A0776/41	CSF Power Transformer, 7.5 kW 6.6A 600V
35A0777/11	CSF Power Transformer, 10 kW 6.6A 208 220 240V
35A0777/21	CSF Power Transformer, 10 kW 6.6A 347 380V
35A0777/31	CSF Power Transformer, 10 kW 6.6A 480V
35A0777/41	CSF Power Transformer, 10 kW 6.6A 600V
35A0778/11	CSF Power Transformer, 15 kW 6.6A 208 220 240V
35A0778/21	CSF Power Transformer, 15 kW 6.6A 347 380V
35A0778/31	CSF Power Transformer, 15 kW 6.6A 480V
35A0778/41	CSF Power Transformer, 15 kW 6.6A 600V
35A0779/11	CSF Power Transformer, 20 kW 6.6A 208 220 240V
35A0779/21	CSF Power Transformer, 20 kW 6.6A 347 380V
35A0779/31	CSF Power Transformer, 20 kW 6.6A 480V
35A0779/41	CSF Power Transformer, 20 kW 6.6A 600V
35A0780/11	CSF Power Transformer, 30 kW 6.6A 208 220 240V
35A0780/21	CSF Power Transformer, 30 kW 6.6A 347 380V
35A0780/31	CSF Power Transformer, 30 kW 6.6A 480V
35A0780/41	CSF Power Transformer, 30 kW 6.6A 600V
35A0794/11	CSF Power Transformer, 5 kW 6.6A 208 220 240V
35A0794/21	CSF Power Transformer, 5 kW 6.6A 347 380V
35A0794/31	CSF Power Transformer, 5 kW 6.6A 480V
35A0794/41	CSF Power Transformer, 5 kW 6.6A 600V
35A0795/11	CSF Power Transformer, 25 kW 6.6A 208 220 240V

PART NUMBER	DESCRIPTION
35A0795/21	CSF Power Transformer, 25 kW 6.6A 347 380V
35A0795/31	CSF Power Transformer, 25 kW 6.6A 480V
35A0795/41	CSF Power Transformer, 25 kW 6.6A 600V

Table 42: CSF/XXXX Power Transformer T1 (20 Amp, 60 Hz Core)

SIZE	208, 220, 240 V 20 A	347, 380 V 20 A	480 V 20 A	600 V 20 A
15 kW	35A0778/12	35A0778/22	35A0778/32	35A0778/42
20 kW	35A0779/12	35A0779/22	35A0779/32	35A0779/42
25 kW	35A0795/12	35A0795/22	35A0795/32	35A0795/42
30 kW	35A0780/12	35A0780/22	35A0780/32	35A0780/42

PART NUMBER	DESCRIPTION
35A0778/12	CSF Power Transformer, 15 kW 20A 208 220 240V
35A0778/22	CSF Power Transformer, 15 kW 20A 347 380V
35A0778/32	CSF Power Transformer, 15 kW 20A 480V
35A0778/42	CSF Power Transformer, 15 kW 20A 600V
35A0779/12	CSF Power Transformer, 20 kW 20A 208 220 240V
35A0779/22	CSF Power Transformer, 20 kW 20A 347 380V
35A0779/32	CSF Power Transformer, 20 kW 20A 480V
35A0779/42	CSF Power Transformer, 20 kW 20A 600V
35A0780/12	CSF Power Transformer, 30 kW 20A 208 220 240V
35A0780/22	CSF Power Transformer, 30 kW 20A 347 380V
35A0780/32	CSF Power Transformer, 30 kW 20A 480V
35A0780/42	CSF Power Transformer, 30 kW 20A 600V
35A0795/12	CSF Power Transformer, 25 kW 20A 208 220 240V
35A0795/22	CSF Power Transformer, 25 kW 20A 347 380V
35A0795/32	CSF Power Transformer, 25 kW 20A 480V
35A0795/42	CSF Power Transformer, 25 kW 20A 600V

Table 43: CSF/XXXX Power Transformer T1 (6.6 Amp, 50 Hz Core)

SIZE	220, 230, 240 V 6.6 A	380, 400 V 6.6 A
2.5 kW	35A0774/51	35A0774/61
4 kW	35A0775/51	35A0775/61
5 kW	35A0794/51	35A0794/61
7.5 kW	35A0776/51	35A0776/61
10 kW	35A0777/51	35A0777/61
15 kW	35A0778/51	35A0778/61
20 kW	35A0779/51	35A0779/61
25 kW	35A0795/51	35A0795/61
30 kW	35A0780/51	35A0780/61

PART NUMBER	DESCRIPTION
35A0774/11	CSF Power Transformer, 2.5 kW 6.6A 220 230 240V 50 Hz
35A0774/21	CSF Power Transformer, 2.5 kW 6.6A 380 400V 50 Hz

PART NUMBER	DESCRIPTION
35A0775/11	CSF Power Transformer, 4 kW 6.6A 220 230 240V 50 Hz
35A0775/21	CSF Power Transformer, 4 kW 6.6A 380 400V 50 Hz
35A0776/11	CSF Power Transformer, 7.5 kW 6.6A 220 230 240V 50 Hz
35A0776/21	CSF Power Transformer, 7.5 kW 6.6A 380 400V 50 Hz
35A0777/11	CSF Power Transformer, 10 kW 6.6A 220 230 240V 50 Hz
35A0777/21	CSF Power Transformer, 10 kW 6.6A 380 400V 50 Hz
35A0778/11	CSF Power Transformer, 15 kW 6.6A 220 230 240V 50 Hz
35A0778/21	CSF Power Transformer, 15 kW 6.6A 380 400V 50 Hz
35A0779/11	CSF Power Transformer, 20 kW 6.6A 220 230 240V 50 Hz
35A0779/21	CSF Power Transformer, 20 kW 6.6A 380 400V 50 Hz
35A0780/11	CSF Power Transformer, 30 kW 6.6A 220 230 240V 50 Hz
35A0780/21	CSF Power Transformer, 30 kW 6.6A 380 400V 50 Hz
35A0794/11	CSF Power Transformer, 5 kW 6.6A 220 230 240V 50 Hz
35A0794/21	CSF Power Transformer, 5 kW 6.6A 380 400V 50 Hz
35A0795/11	CSF Power Transformer, 25 kW 6.6A 220 230 240V 50 Hz
35A0795/21	CSF Power Transformer, 25 kW 6.6A 380 400V 50 Hz

Table 44: CSF/XXXX Power Transformer T1 (20 Amp, 50 Hz Core)

SIZE	220, 230, 240 V 20 A	380, 400 V 20 A
15 kW	35A0778/52	35A0778/62
20 kW	35A0779/52	35A0779/62
25 kW	35A0795/52	35A0795/62
30 kW	35A0780/52	35A0780/62

PART NUMBER	DESCRIPTION
35A0778/52	CSF Power Transformer, 15 kW 20A 220 230 240V 50 Hz
35A0778/62	CSF Power Transformer, 15 kW 20A 380 400V 50 Hz
35A0779/52	CSF Power Transformer, 20 kW 20A 220 230 240V 50 Hz
35A0779/62	CSF Power Transformer, 20 kW 20A 380 400V 50 Hz
35A0780/52	CSF Power Transformer, 30 kW 20A 220 230 240V 50 Hz
35A0780/62	CSF Power Transformer, 30 kW 20A 380 400V 50 Hz
35A0795/52	CSF Power Transformer, 25 kW 20A 220 230 240V 50 Hz
35A0795/62	CSF Power Transformer, 25 kW 20A 380 400V 50 Hz

5.2.4 L-828 General Troubleshooting

This subsection provides general troubleshooting procedures for the L-828 CCR.



WARNING

Read the instructions in their entirety before starting installation.

Only personnel authorized to work on high-voltage equipment should perform maintenance on the regulator.

Since high open-circuit voltages may result by opening the primary of a series lighting circuit, only personnel authorized to work on high-voltage equipment should be allowed to perform the open-circuit test.

Operating a regulator for long periods of time while seriously overloaded may cause the regulator to overheat.

Table 45: CSF Troubleshooting

Problem	Possible Cause	Corrective Action
1. Regulator not turning on	Main power supply off	Verify presence of input voltage.
	Switched off due to overcurrent	Switch regulator off in local. Wait for 2 seconds and check to see if the regulator now operates correctly.
	Incorrect external wiring	If the regulator works correctly in local but not in Remote, check the Remote control signals.
	Blown fuse	Replace any blown fuse. Check the input supply voltage and make sure that it is between -5% and +10% of the nominal value listed on the CCR nameplate.
	Defective Control PCB	Replace Control PCB .
2. Regulator turns on but de-energizes suddenly	Output circuit interrupted	Apply a short to the regulator output. Turn the regulator on. If the regulator works correctly, repair the lighting circuit. Follow all safety precautions in this manual.
	Defective printed circuit board	Replace regulator controller.
	Overcurrent condition	Verify that SCR is triggering by replacing the PCB.
		Check feedback transformer T5 for damage and proper connections. Polarity does not affect operation. Compare input voltages across J8-4 to J8-3 with those in "Output Current Monitor Circuitry" on page 5. If the voltage at the terminals is correct for the selected step and the output is not correct, and the difference cannot be corrected by calibrating the regulator as specified in <i>Output Current Adjustment</i> in the Operation section.
		Check SCRs and wiring.
		Replace SCR.
		Refer to Problem #11 in this table.
3. Output Current always 6.6 A/20 A or more	Universal regulator controller not calibrated	Calibrate the CCR as shown in "CCR Adjustment Procedures" on page 24. Check remaining steps to verify the values from "Output Current and Limits" on page 12.
	Overcurrent condition	Refer to problem #2 in this table, <i>Regulator turns on but de-energizes suddenly</i> .
	Defective control board	If problem exists in Remote and local control, replace regulator controller.
4. Output Current always 4.8 A or less for 3-Step CCR or 2.8 A or less for 5-Step CCR or 8.5 or less on 20 A	SCRs always conducting	Verify SCR is triggering by replacing PCB. Check SCRs and wiring for shorts in SCR circuitry. Replace SCR.
	Defective Ferroresonant resonant circuit (transformer or capacitor)	Visually inspect capacitors for damaged housing or wire connections. Visually inspect transformer for damaged coils, connections, and/or wiring. Faulty capacitors will exhibit a bulging case.
	CCR overload	Remove section of load.

Problem	Possible Cause	Corrective Action
5. More than 2 seconds required for CCR to de-energize on open-circuit load	Faulty overcurrent protection	Replace Control PCB .
6. Short lamp life and/or high output current reading on panel ammeter	Incorrect output current adjustment	Calibrate the CCR as shown in "CCR Adjustment Procedures" on page 24.
	Faulty overcurrent protection	Replace Control PCB .
7. Regulator not indicating proper current	Incorrect output current adjustment	Refer to Output Current Adjustment in the Operation section. Refer to Problem #11 in this table.
	Current meter not calibrated or faulty	Turn the regulator to the top step (6.6 A/20 A). Verify the current with a true-rms current meter. If the meter is not accurate, adjust the meter with the screw on the front cover. For systems equipped with ACE, refer to:
		<ul style="list-style-type: none"> Advanced Control Equipment (ACE) manual 96A0287 or Advanced Control Equipment (ACE2) manual 96A0357 for display calibration procedures.
8. Regulator operates by the local control switch but not by Remote control	The rotary switch on the input module not set to REM	Set the rotary switch to REM.
	Blown fuse	Check fuse F5.
	Loose or broken Remote control wires	Check connections on Remote terminal block TB1. If 120 Vac Remote control signals are used, use an AC voltmeter (300 Vac scale) to verify correct signals are received at the CCR.
	Incorrect wire connections	Refer to Table 12 through Table 14.
9. Ammeter on CCR oscillates and loud noise occurs	SCR drive not working properly	Check connections at SCR module. Replace Control PCB .
		Refer to Problem #11 in this table.
10. Output current not able to be adjusted up to 6.6 A/20 A	Regulator load too large	Either reduce the load or replace the regulator with a larger kW CCR.
		When overloaded, the regulator may make a faint bouncing sound as the controller bounces against the upper control limits. NOTE: This problem can also be verified by shorting the output of the CCR and verifying output current can be adjusted correctly in each step.
11. 5-Step regulator (in Steps 1 or 2) emitting loud hum, not indicating proper current, and operating erratically	Light inductive load (for example, signs)	Increase load on regulator.
		If you cannot increase the load, verify that you are dealing with the right problem by placing a current clamp on the output of the regulator and measuring the frequency of the output. Investigate to see if the problem occurs in Highest Step

5.3 Additional L-829 General Troubleshooting Procedures

For additional L-829 CCR general troubleshooting procedures, refer to the *Troubleshooting* section in manuals:


- 96A0287, Advanced Control Equipment (ACE™) or
- 96A0357, Advanced Control Equipment (ACE2™).

5.4 Component Replacement Procedures

5.4.1 Removing and Replacing Control PCB

1. Turn CCR local switch to the OFF position.

Figure 26: Control PCB




2. Remove and lock out/tag out primary power to the CCR at the breaker panel.
3. Lock out/tag out the SCO in the maintenance position.
4. Loosen the door latch screws and open the CCR door.
5. Unplug green connectors J8, J1, J2, J3, J4, and J5 from the PCB.
6. Disconnect the ribbon cable from J6 by pressing out on the tabs at both sides of the ribbon connection and pull the cable away from the board.
7. Remove the 4 screws at the 4 corners of the PCB. Remove the ground wire from the top right corner. Remove and label the ground wire from the top left corner of the PCB.
8. Mount the new PCB by replacing the 4 screws at the corners of the PCB including the ground wire on the top right corner.
9. Plug the ribbon cable back into J6 by pressing it in. It is keyed and will only go in one way. Also verify the tabs on the side have locked into place.
10. Plug in all of the green connectors to the board. J8, J1, J2, J3, J4, and J5.
11. Close the CCR door and loosen the door latch screws.
12. Restore the SCO to the ON position.
13. Restore primary power to the CCR at the breaker panel.
14. Turn the CCR local switch to the REM position.

5.4.2 Removing and Replacing Dual SCR Module Assembly

See Internal Wiring Schematic, 43A4028.dwg in "Wiring Schematics" on page 59.

Figure 27: Dual SCR Module Assembly




#10 Split Lock Washer (2 or 4 each)
and
1/4-20 X 1/2 Hex Head Screw (2 or 4 each)

1. Turn CCR local switch to the OFF position.
2. Remove and lock out/tag out primary power to the CCR at the breaker panel.
3. Lock out/tag out the SCO in the maintenance position.
4. Open the CCR front door by loosening the 3 door screws.
5. Remove wire 300 and the ground wire from the top lug of the SCR using a 11/16-inch socket. *note: There are different versions of this SCR so hardware may vary.
6. Remove wire 301 from the bottom lug of the SCR using a 11/16-inch socket.
7. Pull the 4 colored gate wires from the bottom of the SCR.
8. Remove the SCR from the regulator by removing the (2) 5/32-hex mounting screws. Clean the heat-sink surface with a dry rag.
9. The replacement SCR will arrive mounted to a rectangular metal plate.
10. Remove the SCR from the attached plate by removing the (2) 5/32-hex mounting screws from the new SCR and the mounting it to the existing plate in the front of the regulator. Place a thin layer of thermal paste on the heat-sink prior to attaching the SCR.
11. Once the SCR is mounted in the CCR, connect wire 300 and the ground wire to the top lug of the SCR.
12. Connect wire 301 to the bottom lug of the SCR.
13. Connect the colored gate wires according to the documentation supplied with the replacement SCR. Different versions of the SCR require these gate wires to be connected in a different order, refer to the documentation shipped with the replacement SCR.
14. Close all doors and replace all panels.
15. Restore the SCO to the ON position.
16. Restore primary power to the CCR at the breaker panel.
17. Turn the CCR local switch to the REM position.

5.4.3 Removing and Replacing Contactor

1. Turn CCR local switch to the OFF position.

Figure 28: CCR Power Contactor



2. Label the wires.
3. Remove and lock out/tag out primary power to the CCR at the breaker panel.
4. Lock out/tag out the SCO in the maintenance position.
5. Open the CCR front door by loosening the 3 door screws.
6. Loosen the wire retaining lugs for 102, 103, 104 and 105 and disconnect. See Internal Wiring Schematic, 43A4028.dwg in "Wiring Schematics" on page 59.
7. Label any wires not labeled prior to disconnecting them.
8. Remove wires 400 and 401 from the top connectors of the contactor.
9. Remove the wires 531 and 501 from the contactor coil connections at the bottom of the contactor.
10. Remove the 3 mounting screws until the contactor is free.
11. Replace the contactor. Tighten the contactor retaining screws on the contactor plate.
12. Connect wires 531 and 501 to the contactor coil connections at the bottom of the contactor.
13. Connect wires 400 and 401 to the top connectors of the contactor.
14. Connect the wires for 102, 103, 104 and 105 and tighten retaining lugs.
15. Close the CCR front door by tightening the 3 door screws.
16. Restore the SCO to the ON position.
17. Restore primary power to the CCR at the breaker panel.
18. Turn the CCR local switch to the REM position.

5.4.4 Removing and Replacing Input Lightning Arrestors (front of Component Mounting Plate)

1. Turn CCR local switch to the OFF position.
2. Remove and lock out/tag out primary power to the CCR at the breaker panel.
3. Lock out/tag out the SCO in the maintenance position.
4. Open the CCR front door by loosening the 3 door screws.
5. Loosen the wire retaining screws for 100, 402, 101, 403, 802 and 803 and disconnect. See Internal Wiring Schematic, 43A4028.dwg in "Wiring Schematics" on page 59.
6. Remove the top two of (4) #10 x 32 pan-head screws and loosen the bottom two screws until the arrestors are free.
7. Replace the Input Lightning Arrestor assembly. Replace the two top screws on the assembly plate and tighten all four until the arrestors are secure.
8. Connect the wires for 100, 402, 101, 403, 802 and 803 and tighten retaining screws.
9. Close the CCR front door by tightening the 3 door screws.
10. Restore the SCO to the ON position.
11. Restore primary power to the CCR at the breaker panel.
12. Turn the CCR local switch to the REM position.

5.4.5 Removing and Replacing Output Lightning Arrestors

(Front of Component Mounting Plate)

1. Turn CCR local switch to the OFF position.
2. Remove and lock out/tag out primary power to the CCR at the breaker panel.
3. Lock out/tag out the SCO in the maintenance position.
4. Remove the side panel of the CCR, by removing the 8 mounting screws. Be careful as you will also need to disconnect the ground wire attached from the frame to the panel.

Figure 29: Output Lightning Arrestors



5. Loosen the 11/16-inch wire retaining nuts for 200, 201, 203, ST1, ST2 and 202 and disconnect.
6. Remove the (4) #10 x 32 pan-head screws and retain until later.
7. Replace the Input Lightning Arrestor assembly. Replace and tighten the screws on the assembly plate.
8. Connect the wires for 200, 201, 203, ST1, ST2 and 202 and tighten retaining nuts.
9. Connect the ground wire from the frame to the side panel.
10. Put the side panel back on the CCR with the 8 screws.
11. Restore the SCO to the ON position.
12. Restore primary power to the CCR at the breaker panel.
13. Turn the CCR local switch to the REM position.

6.0 Parts and Mechanical Drawings

Figure 30: Ordering Codes




Figure 31: CSFXXX-XXXX





Figure 32: CSFXXX-XXXX




ITEM NO.	PART NUMBER	DESCRIPTION	CSF6630
1	42A0525-X	LOCAL CONTROL LABEL, 3 OR 5 STEP (CONFIG.)	1
2	44A6178-X	PCB ASSY 34-PIN HDR/SW ADAPTOR 3(5)-STEP	1
3	44A7050/S66	L-828 METER KIT, SIG SRS REGULATORS	1
4	44A7306/305	CAP PLATE ASSEMBLY, CSF, 30KW, 50HZ	1
5	45A0303	INTRLCK SWITCH DPDT 10A ON-ON	1
6	56A0627	CSF FRAME ASSEMBLY	1
7	60A4426	INTERLOCK SW BRACKET, CSF	1
8	61A0340	KNOB 3FLUTE 1/8"SHAFT ALUM BLK	1
9	64A0198-6	6-32 X 3/8 PAN HD PHIL	2
10	64A1021/16	M8 HEX BOLT SS (18-8) FULL THD. X 16MM LG	6
11	66A0015/26	5/16 FLATWASHER	6
12	66A0039-8	5/16" EXT LOCKWASHER	7
13	66A0039/4	#6 EXT LOCKWASHER	2
14	72A0010	GROUND LUG	1
15	85A0107	CLIP NUT, 8MM, RITTAL	6
18	85A0108	Torx Screws, M5.5 x 13	8
17	89A0209-24	RIBBON CABLE ASSY,34-POS W/CONNS,24"	1
18	91A0033	LBL L828 DANGER HIGH VOLTAGE	1
19	94A0638-XXXX	PWR WIRE KIT, "CSF" SERIES REG'S, { KW & VOLT }	1
20	44A7312-XXXX	COMPONENT PLATE ASSEM., CSF	1
21	35A0780	PWR TX. 30KW, 600V : 6.6A, FERRO	1

- NOTES:
- SEE SHEET 1 OF 3 FOR CONFIGURATION MAPPING. SEE SHEET 3 OF 3 FOR L-829 INFO.
 - S1 AND DIGITAL POWER METER OPTIONS ARE ADDED AT COMPONENT PLATE LEVEL. DRIVE 94A0341 FOR S1. DRIVE 94A0425 FOR DPM.
 - SMI & SMR OPTIONS ARE ADDED AT COMP. PLT. LEVEL. DRIVE 94A0334P (94A0334/20P FOR 20A)/FOR SMR. DRIVE 94A0335P FOR SMI.
 - A LEGIBLE COPY OF 43A4028 WIRING SCHEMATIC IS TO BE PERMANENTLY MOUNTED IN AN UNOBSTRUCTED PLACE INSIDE THE CONTROL CABINET.
 - PANELS ARE HIDDEN FROM VIEW FOR CLARITY.

				CONTROLLED COPY			
				Unauthorized duplication of this document in whole or part is prohibited. Initialed in RED ink below indicates authorized copy.			
				INITIAL & DATE _____			
				ADB			
				Airfield Solutions P.O. BOX 30829 Tel. (614) 861-1304 977 Gahanna Parkway Fax. (614) 864-2069 Columbus, Ohio 43230			
				DRAWING TITLE: CONSTANT CURRENT REGULATOR 4-30KW, 6.6A, 15-30KW, 20A L-828, L-829 208-600V FINAL ASSEMBLY			
A-01	----	PRODUCTION RELEASE	JEG	29OCT12			
REV LEVEL	ECO NUMBER	REVISION DESCRIPTION	DRAWN BY	REV DATE			
ASSOCIATED DRAWINGS: C120002-F100		DRAWN BY: JIM GAFFNEY	DRAWN DATE: 29OCT12		SCALE: 1:6	SHEET NUMBER: 2 OF 3	
Information contained on this drawing is to be used expressly in accord with purpose for which it was submitted. Any disclosure of this information is strictly prohibited except as ADB Airfield Solutions, Inc. may otherwise agree in writing. Copyright 2012 ADB Airfield Solutions.					DRAWING NUMBER: CSFXXXX-XXXX	REV: A-01	

Figure 33: CSFXXX-XXXX



NOTE: For the ACE to Control PCB internal wiring diagram for Ferroresonant CCRs (3 and 5 Step), refer to the Wiring Schematics section in Advanced Control Equipment (ACE) manual 96A0287 or Advanced Control Equipment (ACE2) manual 96A0357.

NOTE: LAND INPUT POWER ON FUSE TERMINALS

INPUT
F1
F2

VR7 VR8

CONTACTOR
K2

SCO MICRO SWITCH
SHEET 2

*T4 INPUT CONNECTIONS
SHEET 2

T4

ATTACH TO FOOT OF T4 -
WIRE #531 MUST BE
CONNECTED AT BLUE WIRE,
NOT TO ANOTHER LOCATION

TYPICAL SCR CONNECTION
SHEET 2

SCR TRIGGER WIRES

T1-FERRO CORE

*T1 CORE CONNECTIONS
SHEET 2

50 VRMS = FULL SCALE

OUT1 TO VR1 WITHOUT CVM
OUT1 TO S14 WITH 6.6A CVM
OUT1 TO T8-P1 WITH 20A CVM

OUT2 TO VR2 WITHOUT MTR
OUT2 TO T2-P1 WITH MTR

CAP BANK

C1
Cx

PT1
PT2

50 VRMS = FULL SCALE

OUT1
OUT2

ST4
ST2
ST1

CVM

DANGER:
LETHAL VOLTAGES
ARE PRESENT

6.6A WIRING SHOWN
SEE SHEET 2 FOR 20A

ANALOG METER
OPTION SHEET 2

OUTPUT
CURRENT
SENSOR

T5
6.6A = 35A0548
20A = 35A0528

CURRENT CLAMP TEST
POINT

IRMS
J3
J4
J5

527
528
529
530
531
532
533

F5 - FUSE
TB1-NEU
TB1-GND

VR1
VR2

TB2

SCO
OPTION

TO AIRFIELD

SCO WIRING
SHEET 2

OUTPUT NOTE:
OUTPUT CONNECTIONS ON VR1
AND VR2 UNLESS TERMINAL
BLOCKS OR "SCO" USED

44A7293/00 PCB

F1F2
0.5A, SB

F3
0.5A, SB

F5 = 0.5A, 250V, SLO-BLOW

527 TO IRMS
528 TO DPM TB

529 TO IRMS
530 TO DPM TB

531 TO IRMS
532 TO DPM TB

533 TO IRMS
534 TO DPM TB

535 TO IRMS
536 TO DPM TB

537 TO IRMS
538 TO DPM TB

539 TO IRMS
540 TO DPM TB

541 TO IRMS
542 TO DPM TB

543 TO IRMS
544 TO DPM TB

545 TO IRMS
546 TO DPM TB

547 TO IRMS
548 TO DPM TB

549 TO IRMS
550 TO DPM TB

551 TO IRMS
552 TO DPM TB

553 TO IRMS
554 TO DPM TB

555 TO IRMS
556 TO DPM TB

557 TO IRMS
558 TO DPM TB

559 TO IRMS
560 TO DPM TB

561 TO IRMS
562 TO DPM TB

563 TO IRMS
564 TO DPM TB

565 TO IRMS
566 TO DPM TB

567 TO IRMS
568 TO DPM TB

569 TO IRMS
570 TO DPM TB

571 TO IRMS
572 TO DPM TB

573 TO IRMS
574 TO DPM TB

575 TO IRMS
576 TO DPM TB

577 TO IRMS
578 TO DPM TB

579 TO IRMS
580 TO DPM TB

581 TO IRMS
582 TO DPM TB

583 TO IRMS
584 TO DPM TB

585 TO IRMS
586 TO DPM TB

587 TO IRMS
588 TO DPM TB

589 TO IRMS
590 TO DPM TB

591 TO IRMS
592 TO DPM TB

593 TO IRMS
594 TO DPM TB

595 TO IRMS
596 TO DPM TB

597 TO IRMS
598 TO DPM TB

599 TO IRMS
600 TO DPM TB

601 TO IRMS
602 TO DPM TB

603 TO IRMS
604 TO DPM TB

605 TO IRMS
606 TO DPM TB

607 TO IRMS
608 TO DPM TB

609 TO IRMS
610 TO DPM TB

611 TO IRMS
612 TO DPM TB

613 TO IRMS
614 TO DPM TB

615 TO IRMS
616 TO DPM TB

617 TO IRMS
618 TO DPM TB

619 TO IRMS
620 TO DPM TB

621 TO IRMS
622 TO DPM TB

623 TO IRMS
624 TO DPM TB

625 TO IRMS
626 TO DPM TB

627 TO IRMS
628 TO DPM TB

629 TO IRMS
630 TO DPM TB

631 TO IRMS
632 TO DPM TB

633 TO IRMS
634 TO DPM TB

635 TO IRMS
636 TO DPM TB

637 TO IRMS
638 TO DPM TB

639 TO IRMS
640 TO DPM TB

641 TO IRMS
642 TO DPM TB

643 TO IRMS
644 TO DPM TB

645 TO IRMS
646 TO DPM TB

647 TO IRMS
648 TO DPM TB

649 TO IRMS
650 TO DPM TB

651 TO IRMS
652 TO DPM TB

653 TO IRMS
654 TO DPM TB

655 TO IRMS
656 TO DPM TB

657 TO IRMS
658 TO DPM TB

659 TO IRMS
660 TO DPM TB

661 TO IRMS
662 TO DPM TB

663 TO IRMS
664 TO DPM TB

665 TO IRMS
666 TO DPM TB

667 TO IRMS
668 TO DPM TB

669 TO IRMS
670 TO DPM TB

671 TO IRMS
672 TO DPM TB

673 TO IRMS
674 TO DPM TB

675 TO IRMS
676 TO DPM TB

677 TO IRMS
678 TO DPM TB

679 TO IRMS
680 TO DPM TB

681 TO IRMS
682 TO DPM TB

683 TO IRMS
684 TO DPM TB

685 TO IRMS
686 TO DPM TB

687 TO IRMS
688 TO DPM TB

689 TO IRMS
690 TO DPM TB

691 TO IRMS
692 TO DPM TB

693 TO IRMS
694 TO DPM TB

695 TO IRMS
696 TO DPM TB

697 TO IRMS
698 TO DPM TB

699 TO IRMS
700 TO DPM TB

701 TO IRMS
702 TO DPM TB

703 TO IRMS
704 TO DPM TB

705 TO IRMS
706 TO DPM TB

707 TO IRMS
708 TO DPM TB

709 TO IRMS
710 TO DPM TB

711 TO IRMS
712 TO DPM TB

713 TO IRMS
714 TO DPM TB

715 TO IRMS
716 TO DPM TB

717 TO IRMS
718 TO DPM TB

719 TO IRMS
720 TO DPM TB

721 TO IRMS
722 TO DPM TB

723 TO IRMS
724 TO DPM TB

725 TO IRMS
726 TO DPM TB

727 TO IRMS
728 TO DPM TB

729 TO IRMS
730 TO DPM TB

731 TO IRMS
732 TO DPM TB

733 TO IRMS
734 TO DPM TB

735 TO IRMS
736 TO DPM TB

737 TO IRMS
738 TO DPM TB

739 TO IRMS
740 TO DPM TB

741 TO IRMS
742 TO DPM TB

743 TO IRMS
744 TO DPM TB

745 TO IRMS
746 TO DPM TB

747 TO IRMS
748 TO DPM TB

749 TO IRMS
750 TO DPM TB

751 TO IRMS
752 TO DPM TB

753 TO IRMS
754 TO DPM TB

755 TO IRMS
756 TO DPM TB

757 TO IRMS
758 TO DPM TB

759 TO IRMS
760 TO DPM TB

761 TO IRMS
762 TO DPM TB

763 TO IRMS
764 TO DPM TB

765 TO IRMS
766 TO DPM TB

767 TO IRMS
768 TO DPM TB

769 TO IRMS
770 TO DPM TB

771 TO IRMS
772 TO DPM TB

773 TO IRMS
774 TO DPM TB

775 TO IRMS
776 TO DPM TB

777 TO IRMS
778 TO DPM TB

779 TO IRMS
780 TO DPM TB

781 TO IRMS
782 TO DPM TB

783 TO IRMS
784 TO DPM TB

785 TO IRMS
786 TO DPM TB

787 TO IRMS
788 TO DPM TB

789 TO IRMS
790 TO DPM TB

791 TO IRMS
792 TO DPM TB

793 TO IRMS
794 TO DPM TB

795 TO IRMS
796 TO DPM TB

797 TO IRMS
798 TO DPM TB

799 TO IRMS
800 TO DPM TB

801 TO IRMS
802 TO DPM TB

803 TO IRMS
804 TO DPM TB

805 TO IRMS
806 TO DPM TB

807 TO IRMS
808 TO DPM TB

809 TO IRMS
810 TO DPM TB

811 TO IRMS
812 TO DPM TB

813 TO IRMS
814 TO DPM TB

815 TO IRMS
816 TO DPM TB

817 TO IRMS
818 TO DPM TB

819 TO IRMS
820 TO DPM TB

821 TO IRMS
822 TO DPM TB

823 TO IRMS
824 TO DPM TB

825 TO IRMS
826 TO DPM TB

827 TO IRMS
828 TO DPM TB

829 TO IRMS
830 TO DPM TB

831 TO IRMS
832 TO DPM TB

833 TO IRMS
834 TO DPM TB

835 TO IRMS
836 TO DPM TB

837 TO IRMS
838 TO DPM TB

839 TO IRMS
840 TO DPM TB

841 TO IRMS
842 TO DPM TB

843 TO IRMS
844 TO DPM TB

845 TO IRMS
846 TO DPM TB

847 TO IRMS
848 TO DPM TB

849 TO IRMS
850 TO DPM TB

851 TO IRMS
852 TO DPM TB

853 TO IRMS
854 TO DPM TB

855 TO IRMS
856 TO DPM TB

857 TO IRMS
858 TO DPM TB

859 TO IRMS
860 TO DPM TB

861 TO IRMS
862 TO DPM TB

863 TO IRMS
864 TO DPM TB

865 TO IRMS
866 TO DPM TB

867 TO IRMS
868

Figure 35: Ferroresonant L828/L829, 4-30kW, 6.6A - 20A , Internal Wiring Schematic (43A4028 2 of 3)




Figure 36: Ferroresonant L828/L829, 4-30kW, 6.6A - 20A , Internal Wiring Schematic (43A4028 3 of 3)

	2.5 KW	4 KW	7.5 KW	10 KW	15 KW	20 KW	25 KW	30 KW
208V, 60HZ	12 AWG 89A0185/9	12 AWG 89A0185/9	8 AWG 89A0196/9	8 AWG 89A0196/9	4 AWG 89A0198/9	1/0 AWG 89A0201/9	1/0 AWG 89A0201/9	1/0 AWG 89A0201/9
240V, 60HZ	12 AWG 89A0185/9	12 AWG 89A0185/9	8 AWG 89A0196/9	8 AWG 89A0196/9	6 AWG 89A0197/9	2 AWG 89A0199/9	2 AWG 89A0199/9	2 AWG 89A0199/9
347V, 60HZ	12 AWG 89A0185/9	12 AWG 89A0185/9	10 AWG 89A0195/9	8 AWG 89A0196/9	6 AWG 89A0197/9	2 AWG 89A0199/9	2 AWG 89A0199/9	2 AWG 89A0199/9
400V, 50HZ	12 AWG 89A0185/9	12 AWG 89A0185/9	10 AWG 89A0195/9	8 AWG 89A0196/9	6 AWG 89A0197/9	2 AWG 89A0199/9	2 AWG 89A0199/9	2 AWG 89A0199/9
480V, 60HZ	12 AWG 89A0185/9	12 AWG 89A0185/9	10 AWG 89A0195/9	8 AWG 89A0196/9	6 AWG 89A0197/9	6 AWG 89A0197/9	6 AWG 89A0197/9	6 AWG 89A0197/9
600V, 60HZ	12 AWG 89A0185/9	12 AWG 89A0185/9	10 AWG 89A0195/9	8 AWG 89A0196/9	6 AWG 89A0197/9	6 AWG 89A0197/9	6 AWG 89A0197/9	6 AWG 89A0197/9

CCR INPUT VOLTAGE	INPUT FUSES F1 & F2								F3 & F4 FUSE RATINGS		INPUT VARISTORS VR1 & VR2	OUTPUT VARISTORS VR7 & VR8
	2.5 KW	4 KW	7.5 KW	10 KW	15 KW	20 KW	25 KW	30 KW	4-10 KW	15-30 KW		
208V, 60HZ	20A, 250V	30A, 250V	50A, 250V	70A, 250V	110A, 250V	150A, 250V	175A, 250V	200A, 250V	2A, 250V	2A, 250V	23A0032	
220V, 60HZ	20A, 250V	30A, 250V	50A, 250V	70A, 250V	110A, 250V	125A, 250V	175A, 250V	200A, 250V	2A, 250V	2A, 250V		
240V, 60HZ	15A, 250V	25A, 250V	45A, 250V	60A, 250V	90A, 250V	125A, 250V	150A, 250V	175A, 250V	2A, 250V	2A, 250V		
347V, 60HZ	10A, 600V	20A, 600V	35A, 600V	40A, 600V	60A, 600V	90A, 600V	100A, 600V	125A, 600V	0.5A, 500V	0.5A, 500V		
400V, 50HZ	10A, 600V	20A, 600V	30A, 600V	40A, 600V	60A, 600V	80A, 600V	90A, 600V	125A, 600V	0.5A, 500V	0.5A, 500V		
480V, 60HZ	8A, 600V	12A, 600V	25A, 600V	30A, 600V	50A, 600V	60A, 600V	80A, 600V	90A, 600V	0.5A, 500V	0.5A, 500V		
600V, 60HZ	6A, 600V	10A, 600V	20A, 600V	25A, 600V	40A, 600V	45A, 600V	60A, 600V	70A, 600V	1A, 600V	1A, 600V		
SCR #	28A0056	28A0056	28A0056	28A0056	28A0057	28A0055	28A0054	28A0054				

CCR INPUT VOLTAGE	INPUT CONTACTOR							
	2.5 KW	4 KW	7.5 KW	10 KW	15 KW	20 KW	25 KW	30 KW
208/220V, 60HZ	53A0412/25	53A0412/30	53A0412/50	53A0412/70	53A0412/120	53A0412/150	53A0412/175	53A0331
240V, 60HZ	53A0412/25	53A0412/30	53A0412/50	53A0412/70	53A0412/120	53A0412/150	53A0412/175	53A0331
347V, 60HZ	53A0412/25	53A0412/25	53A0412/40	53A0412/40	53A0412/60	53A0412/90	53A0412/120	53A0412/150
400V, 50HZ	53A0412/25	53A0412/25	53A0412/40	53A0412/40	53A0412/60	53A0412/90	53A0412/90	53A0412/150
480V, 60HZ	53A0412/25	53A0412/25	53A0412/40	53A0412/40	53A0412/50	53A0412/60	53A0412/90	53A0412/90
600V, 60HZ	53A0412/25	53A0412/25	53A0412/25	53A0412/25	53A0412/40	53A0412/50	53A0412/60	53A0412/75

CCR INPUT FREQUENCY	CAP BANK ASSEMBLY							
	2.5 KW	4 KW	7.5 KW	10 KW	15 KW	20 KW	25 KW	30 KW
50HZ	44A7306/025	44A7306/045	44A7306/075	44A7306/105	44A7306/155	44A7306/205	44A7306/255	44A7306/305
60HZ	44A7306/026	44A7306/046	44A7306/076	44A7306/106	44A7306/156	44A7306/206	44A7306/256	44A7306/306

WIRE & ASSEMBLY NOTES _____ :

1. WIRE SIZES:
100-105: INPUT POWER, SEE TABLE (ALL WIRES 600V, 105°C).
200-213: HIGH VOLTAGE, 12AWG, 25KV, 150°C, 89A0086/1.
400-409: MEDIUM CURRENT, 12AWG, 600V, 105°C, 89A0185/9
500-535: CONTROL, 18AWG, 600V, 105°C, 89A0182/9.
800-804: GROUND, 12AWG, 600V, GN/YL, 89A163/5.
900-912: GROUND, 18AWG, 600V, GN/YL, 89A0163/7.
2. GROUNDING NOTES:
- EACH PANEL CONNECTS ELECTRICALLY TO THE FRAME OR CHASSIS GROUND.
- JUMPER INTERNAL GND LUG TO EXTERNAL GND LUG.
3. ROUTE POWER WIRES SEPARATE FROM CONTROL WIRES.
4. TORQUE ALL CONTACTOR CONNECTIONS PER CONTACTOR PRODUCT LABEL.

44A7318/1	FERRO CNTRL. PNL. WIRE HARNESS, ALL ENCLOSURES
44A6139/1-2	FERRO/ACE WIRE HARNESS, ALL ENCLOSURES
94A0638/XXXX	POWER WIRE KIT, "CSH" FERRO CCR
43A3128	WIRING DIAGRAM, ACE2 TO URCL/1 PCB
DOC. NO.	DESCRIPTION

RELATED DOCUMENTS

DRAWING TITLE: WIRING DIAGRAM, L-828 WITH URCLII, 2.5KW TO 30KW, 66A & 20A, "OSF" FERRO REGULATOR	REV B-01	A REVISION REVISION DESCRIPTION	BE 26JUL12	BE 26JUL12	DRAWN REV DATE	REVISION DESCRIPTION	ASSOCIATED DRAWING: DRAWN BY: backwards DRAWN DATE: 7/26/2012	CONTROLLED COPY One hard copy of this drawing and one electronic copy must be maintained in RED file below indicate authorized copy. INITIAL & DATE:
SHEET 3 OF 3								
DRAWING NUMBER: 43A4028								
PREPARED BY:								
ADB Arfield Solutions 977 Gahanna Parkway, Columbus, Ohio 43230 Telephone: 614-861-1304 Fax: 614-864-2069 Copyright © 2012 ADB Arfield Solutions.								

Registered office:

ADB Airfield Solutions LLC
977 Gahanna Parkway
Columbus, OH 43230
USA
Phone: +1 (614) 8611 304
Fax: +1 (614) 8642 069

Other addresses:

ADB Airfield Solutions Ltd.
5500 North Service Road, Suite 1108
Burlington, Ontario L7L 6W6
Canada
Phone: +1 (905) 331 6887
Fax: +1 (905) 331 9389

ADB Airfield Technologies Ltd.
01A Unit, 9F, LSH Plaza
8, Wangjing Jie
Chaoyang District
Beijing 100102
P.R. China
Phone: +86 10 8476 0106
Fax: +86 10 8476 0090

ADB N.V.
Dubai Silicon Oasis
Wing D - Office D-309
P.O. Box 341218
United Arab Emirates
Phone: + 971 4372 4970
Fax: + 971 4372 4975

ADB N.V./S.A.
39/47 Boulevard Ornano
93200 Saint-Denis

France
Phone: +33 (1) 4922 9250
Fax: +33 (1) 4922 9255

ADB Airfield Solutions GmbH & Co. KG
Von-der-Tannstr. 31
90439 Nürnberg
Germany
Phone: +49 (911) 9239 1287
Fax: +49 (911) 2852 582

ADB N.V.
Asia Pacific Regional HQ
Unit C-9.3.1, Level 9, Block C
Mines Waterfront Business Park
No. 3, Jalan Tasik
The Mines Resort City
43300 Seri Kembangan Selangor
Malaysia
Phone: +603 8941 4868
Fax: +603 8942 4869

ADB Airfield Solutions Netherlands
Prinses Beatrixlaan 614
Office D3.14
2595 BM Den Haag
The Netherlands
Phone: +31 (0)70 304 3611
Fax: +31 (0)70 333 8094

ADB Airfield Solutions, Ltd.
2nd Floor, 3 Rivonia Village
Cnr Mutual Road and Rivonia Boulevard
South
Rivonia 2128
South Africa
Phone: +27 (11)234 6768
Fax: +27 (11)234 6739

ADB
Unit 44, Business Innovation Centre
Binley Business Park
Harry Weston Road
Coventry, CV3 2TX
United kingdom
Phone: +44 (0)1455 883130
Fax: +44 (0)1455 883179

ADB
Airfield Solutions
Leuvensesteenweg 585
B-1930 Zaventem
Belgium
Phone: +32 (2) 722 17 11
Fax: +32 (2) 722 17 64
info.adb@adb-air.com
www.adb-air.com

